



PHONES

0 (800) 800 130
(050) 462 0 130
(063) 462 0 130
(067) 462 0 130

130
COM.UA

Internet store of
autogoods



SKYPE

km-130

CAR RECEIVERS — Receivers • Media receivers and stations • Native receivers • CD/DVD changers • FM-modulators/USB adapters • Flash memory • Facia plates and adapters • Antennas • Accessories |
CAR AUDIO — Car audio speakers • Amplifiers • Subwoofers • Processors • Crossovers • Headphones • Accessories | TRIP COMPUTERS — Universal computers • Model computers • Accessories |
GPS NAVIGATORS — Portable GPS • Built-in GPS • GPS modules • GPS trackers • Antennas for GPS navigators • Accessories | VIDEO — DVR • TV sets and monitors • Car TV tuners • Cameras • Videomodules • Transcoders • Car TV antennas • Accessories | SECURITY SYSTEMS — Car alarms • Bike alarms • Mechanical blockers • Immobilizers • Sensors • Accessories | OPTIC AND LIGHT — Xenon • Bixenon • Lamps • LED • Stroboscopes • Optic and Headlights • Washers • Light, rain sensors • Accessories | PARKTRONICS AND MIRRORS — Rear parktronic • Front parktronic • Combined parktronic • Rear-view mirrors • Accessories | HEATING AND COOLING — Seat heaters • Mirrors heaters • Screen-wipers heaters • Engine heaters • Auto-refrigerators • Air conditioning units • Accessories | TUNING — Vibro-isolation • Noise-isolation • Tint films • Accessories | ACCESSORIES — Radar-detectors • Handsfree, Bluetooth • Windowlifters • Compressors • Beeps, loudspeakers • Measuring instruments • Cleaners • Car seats • Miscellaneous | MOUNTING — Installation kits • Upholstery • Grilles • Tubes • Cable and wire • Tools • Miscellaneous | POWER — Batteries • Converters • Start-charging equipment • Capacitors • Accessories | MARINE AUDIO AND ELECTRONICS — Marine receivers • Marine audio speakers • Marine subwoofers • Marine amplifiers • Accessories | CAR CARE PRODUCTS — Additives • Washer fluid • Care accessories • Car polish • Flavors • Adhesives and sealants | LIQUID AND OIL — Motor oil • Transmission oil • Brake fluid • Antifreeze • Technical lubricant



In store "130" you can find and buy almost all necessary goods for your auto in Kyiv and other cities, delivery by ground and postal services. Our experienced consultants will provide you with exhaustive information and help you to choose the very particular thing. We are waiting for you at the address

<https://130.com.ua>



BALTIC CAR EQUIPMENT

Fleet management systems

Vehicle security systems

Telemetry solutions

www.bce.lt

FM Blue/Blue+



User manual

Version 1.1



Contents

1.	FM Blue/Blue+ device information	- 3 -
1.1.	Safety and legal information	- 3 -
1.2.	Description	- 3 -
1.3.	Package.....	- 3 -
1.4.	Technical specifications	- 4 -
1.5.	Physical properties	- 5 -
1.6.	Pinout & diagnostic LEDs.....	- 7 -
1.6.1.	Pinout	- 7 -
1.6.2.	Diagnostic LEDs	- 8 -
1.7.	Installation	- 9 -
1.8.	Configuration.....	- 10 -
1.9.	Support	- 10 -
1.10.	Document versions	- 10 -
2.	Annex 1. Installation instructions	- 11 -
3.	Annex 2. Configuration manual.....	- 16 -
3.1.	BCE Device Configuration Manager	- 16 -
3.1.1.	Users and Dealers.....	- 16 -
3.1.2.	Devices and Retranslators	- 17 -
3.1.3.	Firmware	- 17 -
3.1.4.	GSM operator groups.....	- 17 -
3.1.5.	XML settings.....	- 17 -
3.2.	BCE Device Settings Wizard	- 18 -
3.2.1.	Simple configuration mode.....	- 19 -
3.2.2.	Advanced configuration mode	- 21 -
3.2.3.	Function signals	- 23 -
3.2.4.	Functions.....	- 24 -
4.	Connecting “Vepamon” LLS fuel level sensors to FM Blue device	- 27 -
4.1.	Frequency mode.	- 27 -
4.1.1.	Connecting one LLS sensor.	- 27 -
4.1.2.	Connecting two LLS sensors.	- 28 -
4.2.	Analog mode	- 29 -
4.2.1.	Connecting one LLS sensor	- 29 -
4.2.2.	Connecting two LLS sensors	- 30 -



1. FM Blue/Blue+ device information

1.1. Safety and legal information



Do not disassemble the device.

May interfere operation of adjacent electronic devices.

Device may be damaged by water and high humidity.

Installed by qualified professionals only.

Copyright © Baltic Car Equipment, Ltd.

All rights reserved. Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without prior written permission of Baltic Car Equipment is strictly prohibited.

1.2. Description

FM Blue+ is a device with GPS and GSM connectivity, designed for object tracking. It is able to acquire information on object location, speed, direction, etc. and transfer the data via GSM network. Digital and analog inputs of the device may be used to connect different external sensors/devices. Outputs of the device may be used to control external equipment remotely. **FM Blue+** is able to read FMS CAN data (protocol J1939) from vehicles. Flexible configuration allows users/dealers to adjust the device to meet their specific requirements.

1.3. Package

FM Blue+ is shipped to a customer in a cardboard box and contains all required components for operation*.

Package contents:

1. **FM Blue+** device (control unit)
2. External GPS antenna
3. External GSM antenna
4. Wires + 1A fuse



Note. SIM card is not included, but is necessary to operate the device. Contact your local GSM operator to purchase a SIM card. BCE recommends a M2M SIM card for best performance and reliability.

1.4. Technical specifications

Table 1. **FM Blue+** technical specifications

FM Blue+	
GSM	Physical properties
850/900/1800/1900 MHz	Dimensions (HxWxD): 26 x 80 x 55 mm
GSM/GPRS protocol stack	Weight: approximately. 73 g
3 GPP Release 4 compliant	
Sensitivity:	Operating temperature range
<-107 dBm @ 850 / 900 MHz	Operation / Storage: -40 C° to +85 C°
<-106 dBm @ 1800 / 1900 MHz	
GPRS class 10 (up to 85.6 kbps), class B	Electrical properties
Jamming detection	Operation's flow:
GPS	Active Mode: at 12V - < 50mA
U-blox Neo 6Q	Sleep Mode: at 12V - < 8mA
	6 – 34V operating voltage, min 10V to start
Precision:	Protection from impulses up to 120V
Position: 2.5m CEP	Power cut-off registration to the event log
Take off time:	
1 second „hot start“ in the open air	Interfaces
< 30 seconds warm start in the open air (average)	4 digital inputs
30 seconds cold start in the open air (average)	3 x ADC:
Sensitivity:	1 ADC: 0..16 V, 11 bit
-148dBm cold start	2 x ADC: 0..36 V, 11 bit
-162dBm tracking	2 digital outputs
Accelerometer	CAN data interface
LIS33DE	1-WIRE
Flash IC	RS-232
4Mb, SPANSION FL032P	EIA485

1.5. Physical properties




Fig. 1. FM Blue+ front view.

Note. To insert a SIM card, loosen device mounting screws at the bottom of the device.

Table 1. FM Blue+ components

No.	Short description
1	Mounting screws place
2	Device box mounting screws
3	Device and GPS status LED
4	GSM status LED
5	GPS antenna socket (blue)
6	GSM antenna socket (purple)
7	IMEI and hardware ID sticker
8	SIM card
9	Socket 2x8 pins




Fig. 2. FM Blue+ dimensions

1.6. Pinout & diagnostic LEDs

1.6.1. Pinout




Fig. 3. FM Blue+ pinout and cable colors.

Electrical properties of the device are shown in Table 2.

Table 2. FM Blue+ electrical properties.

ADC Power supply multiplier (adc2)	0.025V +/-1.5% ADC 11bit
ADC 3 multiplier (adc3)	0.01V +/-1.5% ADC 11bit max 20V
ADC4 multiplier (adc4)	0.0205V +/-1.5% ADC 11bit max 40V

ADC5 multiplier (adc5)	0.0205V +-1.5% ADC 11bit max 40V
ADC EXTBAT multiplier (adc6)	0.0205V +-1.5% ADC 11bit max 40V
EXT BAT OUT (+)	13.5V regulated 1.5A limited
OUT1 (-)	1.7A
OUT2 (-)	1.7A
Power supply, min start up voltage	10V
Power supply, min operating voltage after start up	6V
Power supply, stage1	30V
Clamping voltage clamping type	34V varistor
IN2,IN3,IN4,IN5 Max measuring frequency, accuracy	3Khz, +/-1Hz
IN2, IN3, IN4, IN5 voltage threshold	4.7V, +/-3%

1.6.2. Diagnostic LEDs

FM Blue+ has two indication LEDs – for GPS and GSM modem status. LEDs start flashing only if IN5 digital input is connected to battery +.




Fig 4. LED flash signal. Example.



Table 3. Short flash meaning. GPS status.

Short flashes count	Meaning
1	No GPS signal
2	Poor precision. HDOP>1.5
3	3 satellites locked. HDOP<1.5
...	...
12	12 satellites locked. HDOP<1.5

Table 4. Long flash meaning. GSM modem status.

Long flashes count	Meaning
1	Modem connected to server, Modem connected to Internet, Modem GPRS registered, Modem GSM registered, Modem SIM card ok, Modem turned on
2	Modem connected to Internet, Modem GPRS registered, Modem GSM registered, Modem SIM card ok, Modem turned on
3	Modem GPRS registered, Modem GSM registered, Modem SIM card ok, Modem turned on
4	Modem GSM registered, Modem SIM card ok, Modem turned on
5	Modem SIM card ok, Modem turned on
6	Modem turned on
7	Device started

1.7. Installation

FM Blue+ is installed where risk of mechanical damage, high humidity and extreme heat is low. Device is mounted stable to vehicle body, therefore ensuring correct operation of the internal accelerometer. Complete installation manual is available as Annex 1.



1.8. Configuration

FM Blue+ is meant to be operated through a configuration/retranslation server, where dealers/users can configure their devices to fulfill specific requirements. Configuration manual is available as Annex 2.

1.9. Support

FM Blue+ is built to be a reliable, stable and easy to install device. Please read and follow provided installation and operating instructions carefully. However, if you encounter difficulties while installing or using this product, technical support is available and may be reached by e-mail support@bce.lt.

1.10. Document versions

Table 5. Document versions

Version	Date	Changes
1.0	2012.03.20	Document created.
1.1	2012.11.09	Updated configuration description, added LLS connection



2. Annex 1. Installation instructions

List of suitable vehicles

FM Blue+ is intended for all vehicles with petrol or diesel engines, where negative pole is body of the vehicle. Device must be connected to the vehicle battery, ensuring constant power supply even if the engine is not working and ignition is off.

When active, **FM Blue+** uses a small amount of direct current (DC) – less than 50 mA at 12V. It can be mounted in 12 V or 24 V vehicles.

Standby mode

This is a mode of the device when the vehicle ignition is turned off, and there are no active alarms. In this mode, the GPS receiver is switched off in the control unit (in order to reduce power consumption) and communication with the server intervals are increased. Device switches to active mode if programmed trigger is detected (for example accelerometer signal).

Active mode

This is a mode when ignition is on, or when any programmed trigger is active. In this mode, GPS receiver is enabled in the central unit and connection with the server is carried out more frequently. After ignition is switched off, the central unit remains active for another 10 minutes.

- Free configuration of data dispatch frequency is possible.
- During the data transfer (GSM / GPRS communications), short-term increase in current consumption of up to 100 mA is possible.
- Power-line (primary or back up battery) has to be connected via 1A fuses.

Basic instructions before beginning the installation

Quality of connections, location of the device and its' antennas, etc. play a significant role on accurate operation of the system. Below are some tips and rules for correct installation to attain professional quality and ensure maximum efficiency of the device.

Location for central unit installation

Central unit should be hidden in a difficult to access location to prevent unwanted interference by unauthorized persons. Small size and flat body makes it easy to do and allows use of small gaps for installation.



The device must be fixed in the vehicle in position where connectors are oriented to the ground. This will prevent moisture condensation inside the unit.

Electrical connections

Control unit must be powered by continuous voltage. When starting the engine, voltage can not fall below 8 V. It is desirable that power supply for the device is connected to the factory cable led from battery terminals. This allows operation of the unit despite of failure of any vehicle fuses.

Mechanical connections

To highest possible extent, cavities in the vehicle should be used for wiring. If you need to make a new hole, it must be protected against corrosion appropriately!

Wiring connection must be made by brazing, and not merely mechanical wire connection. It is especially important to protect the connections with insulation for high-resistance atmospheric conditions. Do not use insulation with unknown resistance parameters.

Efforts should be made to tie the new wiring into the car's standard wiring bales.

Installation of central unit

Steps to install central unit:

- Insert a SIM card into the device;
- Install GSM and GPS antennas;
- Install central unit;
- Connect power supply;
- Connect array;
- Connect ignition wire to a digital input (usually IN5);
- Connect other devices (optional).

SIM card

SIM card must be inserted into the device before starting installation. The device must be turned off when inserting SIM card. Before inserting the SIM card, make sure you have activated GPRS connection, the card's PIN code must be disabled.

If the vehicle is travelling to foreign countries, roaming service must be activated for the SIM card. The SIM card and phone number must be checked and clearly marked on the installation certificate of the device.



IMPORTANT! Before inserting a SIM card, do not forget to disable PIN code. Otherwise, the device will not work, and the SIM card will be blocked.

GPS antenna installation

GPS antenna is the main element responsible for vehicle positioning accuracy and quality. To ensure best possible GPS signal reception and evaluating GPS signal character, there are strict requirements for correct installation of GPS antenna:

- The accordingly marked side of the antenna must be invariably directed to the sky (sticky side facing ground). The antenna must be oriented horizontally (not at an angle) and oriented with the corresponding side towards the top.
- The antenna should not be covered with metal sheet or reinforced glass. In vehicles with standard glass (e.g., without built-in heating elements), antennas can be mounted on panels or under its lining at the windscreen. The antenna must have open view to the sky, unimpeded with windowsills or other metallic elements.
- In vehicles where it is not possible to place the antenna under the windscreen (vertical windscreen, armored glass), the antenna can be installed in the vehicle's bumper or in other element that ensures the free access to the sky.
- The installed antenna should be hidden and not visible.
- Fixing of the antenna must be stable and immobile, providing for the installation durability. It is necessary to take into account events, which may lead to loss of antenna's stability, to select the mounting location and methods that would allow to avoid these factors. Antenna's position changes are not permitted, because it may result in loss of appropriate antenna's orientation.
- Cable to the GPS antenna must be as short as possible, and avoid areas with high electromagnetic interferences. Arbitrary lengthening or shortening of the cable is not allowed. The wire surplus should be twisted into a circle with a radius larger than 10 cm. The cable must not be bent, or twisted at tight angles. GPS antenna cable must not be laid in parallel to GSM antenna cable, also the two cables cannot be twisted together.

GSM antenna installation

GSM antenna is responsible for transfer of collected data and connection with central server. Good antenna's performance is the key element in obtaining information from the device.



GSM antenna does not require orientation to open sky; however you should be aware that metal elements weaken the GSM signal.

GSM antenna must be placed in the panel upholstery, or in a place which provides a good GSM signal reception (avoid excessive covering with metal sheet).

GSM antenna must be installed in more than 40 cm away from the control unit, as well as from other electronic devices. It is also necessary to take into account the emission of the antenna's high frequency radio waves, which may interfere with operation of electronic devices.

In case antenna is difficult to place in the cabin (strong GSM signal suppression), it may be installed in any other element allowing the reception of the GSM signal. As for GPS antenna, GSM antenna should be hidden from outside observers.

Device installation

Central unit is only mounted in inside of the vehicle, it can not be installed in the engine chamber, next to the cabin, or in the area of exposure to direct external conditions. Central unit must be hidden (for example, under the upholstery), as well as protected from moisture exposure. Device must be fastened in a stable position to avoid random twitches and displacements (suspension on cables is strictly prohibited). Central unit must be mounted horizontally. Precise orientation is of particular importance to flawless operation of the system, since the device is equipped with acceleration sensors recording the data which directly affects the results obtained. Pinout and cable colors are shown in figure 1.

EIA 485B green/black, 20 AWG		EIA 485A, green, 20 AWG
RS 232 RX, blue, 20 AWG		RS 232 TX, purple, 20 AWG
CAN H (+), orange/black, 26 AWG		CAN L (-), orange, 26 AWG
ADC5/OUT1, gray, 26 AWG		1-Wire, yellow, 26 AWG
ADC3, white, 26 AWG		IN2, green/black, 26 AWG
EXT BAT/ADC6, brown, 20 AWG		IN3, purple/black, 26 AWG
BATTERY +, red, 20 AWG		IN4, blue/black, 26 AWG
GROUND, black, 20 AWG		IN5, gray/black, 26 AWG

Annex 1. Fig. 1. FM Blue+ pinout. Wire side.



Power supply

Power supply of central unit has to be connected directly from the vehicle's battery, using 1A fuse.

***IMPORTANT!** Power supply may be connected to the central unit only after connecting GSM and GPS antennas! When disconnecting the device, you must first turn off the power supply, and only then disconnect the antennas!*

Ground wire

Ground wire should be connected to the vehicle body. A reliable electrical contact with the body must be ensured, wire has to be bolted.

Ignition input (combustion lock status)

Connect a wire of the vehicle where voltage is present only when ignition is activated to IN5.

Universal digital inputs (optional)

Universal Digital inputs (IN2; IN3; IN4; IN5) are intended to collect data from remote devices.

Analog inputs (optional)


Analog inputs are intended to collect data from remote devices by measuring voltage. ADC3 range 0-20V; ADC4, ADC5, ADC6 range 0-40V.

3. Annex 2. Configuration manual

3.1. BCE Device Configuration Manager

BCE Configuration Manager is a web based service for adding new devices, changing device settings, firmware, operators, creating retranslations and more. This service allows you to configure and manage your devices remotely.

You may access it at <http://fmset.eu> if you have an account.



Annex 2. Fig. 1. Fleet management system scheme

3.1.1. Users and Dealers

Each dealer has an account and can control all his devices via BCE Device Configuration Manager. If the dealer has a network of dealers, he can control the sub-dealers and their devices. Do not forget to select the parent dealer when creating new dealers and devices.

After creating the devices you can change the dealer for one or a group of them. In the “Devices” tab select the devices you want to change the dealer for, click “Transfer selected devices”, select the dealer you need and click “Transfer”.



3.1.2. Devices and Retranslators

To create a new device, click on “New device”, select the hardware version, click “Next”, enter the IMEI number and the telephone number of the SIM card in your device. ICCID and IMSI will be read from the SIM card automatically. When creating a device, you can also change other settings – firmware, operator list, XML settings, dealer, server, APN, SMS numbers and custom values. You will be able to change them later.

Retranslators can be used to connect the device to different networks using popular protocols. To create a new retranslator, click on a device in the “Devices” tab, go to “Retranslators”, select the protocol, enter the server IP address and port (f.e. 100.100.100.100:2222). You can duplicate a single device by creating several retranslators to different servers.

3.1.3. Firmware

Firmware versions depend on hardware versions of the device. Firmware version marked K is used on hardware versions 4.0 and 4.1, L – 4.5, M – 5.0. The higher the number of the firmware – the newer it is. Firmware versions are created and uploaded by the BCE team.

3.1.4. GSM operator groups

You can create and edit preferred operator lists. Each list belongs to a certain dealer, however, you can create several lists for a dealer and set different list of operators for each device.

3.1.5. XML settings

XML settings may be uploaded to the device and used to tune it for the best performance and requirements of your system. You will find several prepared settings created by our team. However, you may use BCE Device Configuration Wizard to create settings that meet your specific needs. After the settings are ready just upload them to the devices.

3.2. BCE Device Settings Wizard

Version 1.3.3

Device settings wizard is an application used to create XML settings for “BCE” hardware. The application has two configuration modes:

1. Simple mode – easier to use, functions changing based on checkboxes and sliders.
2. Advanced mode – more complicated, but gives more possibilities to change device settings. Has more functions included, which make your device very flexible.

Configuration file is saved in a special “dswiz” format and uploaded directly to www.fmset.eu → XML settings. File also can be exported in following formats:

1. Binary
2. ASCII binary
3. Wialon xml


When settings are configured, it is very important to pick the right version of the device before saving.

There are three possible versions:

1. 4.0
2. 4.5
3. 5.0

You can find the version written on the device – HW/ID, f.e. 1-**51**-01 (need to look at the second number), this marking means that you are using 5.0 version.


Note. You will need to pick the version while creating a new device in fmset.eu as well.



Picture1. Device version selection

3.2.1. Simple configuration mode

This mode is a very simple and quick way to change your settings. Just select functions group which you see in the left side of configuration window (picture2.). Functions state is changed with sliders or checkboxes, depending on a specific function. Usually you have select particular value (slider) or enable/disable a feature (checkbox).



Picture2. Simple configuration mode

Functions group review.

Vehicle wake up input

Vehicle wake up input defines conditions on which the vehicle is considered active. Several conditions may be selected. Intensity of vibration to detect activity may be adjusted.

Device power mode

Device may be always active or activated only if ignition is on or movement is detected. It goes to sleep mode when the vehicle charging voltage falls. Voltage level is adjustable.



Remote connection mode

Remote connection defines how often the device connects to server. Usually it is always connected while in home country and connected on ignition when abroad. In that case, when the ignition is off, the device sends data packets periodically to save data traffic.

GPS data fix mode

GPS data fix mode allows you to configure the accuracy of vehicle track, the device records and minimum requirements for connection quality. The smaller the values in the “Course change” and “Speed change” fields, the more points are recorded and therefore more accurate track is displayed. However, this results in higher data traffic.

GPS coordinate timeout is the maximum period between recorded points if the vehicle has not changed its course or speed enough to record a point.

Minimum requirements for signal quality may be set by defining minimum number of satellites to be locked and maximum HDOP value.

Floating size dataset

The size of data messages recorded and sent by the device is variable. It may be changed by selecting more/less traced values. This may be configured separately for ignition on/off, home country and abroad. If you want to send messages with all values included, unselect “Use floating size dataset”.

Digital inputs fix mode

The values of sensors connected to the selected inputs will be recorded. Maximum period between records may be set.

Counter/frequency mode

The device can register the number or frequency of changes in sensor values (counter/frequency mode). Maximum period between records may be set.

Operator list


Operator list may be edited in “Device settings wizard”, as well as in “BCE device configuration manager (fmset.eu)”.

3.2.2. Advanced configuration mode

Most fleet management systems and GPS tracking devices on the market are configured by manufacturers with little possibilities for adjustment. “BCE” device configuration system allows you to create unique settings for different and specific needs in fleet management by dynamically changing most settings of device. We hope you will enjoy the results of your configurations.

Advanced configuration mode designed to make “BCE” device settings widely adjustable. Settings functions may be adjusted dynamically depending on internal, external and virtual device signals and signals conditions. Every logical item has its own value. One function can have more than one logical item. Logical item values depend on signal conditions.

Table of device settings in advanced mode



Settings function name

Functions

Logical item value

Logical item signal condition

Logical items control list of function parameters

Total number of logical items


Parameters count: 51

Configuration file name: default.dswiz

Function Name	Logical Item	Signal Condition	Value
F_ModemPowerMode	1	00000000	00000000
	1	00000000	00000000
F_GPSPowerMode	1	00000000	00000000
	1	00000000	00000000
F_InternetConnection	1	00080200	00080000
	1	02000200	02000000
	1	04000200	04000000
	1	00400200	00400000
	0	06480200	00000000
	0	00000200	00000200
F_RemoteServer	1	00080200	00080000
	1	02000200	02000000
	1	04000200	04000000
	1	00400200	00400000
	0	06480200	00000000
	0	00000200	00000200
F_GPSFilterInputPeriod	1	00080000	00080000
	3600	00080000	00000000
F_MaxStackFixPeriod	60	00000200	00000000
	60	00000200	00000200
F_CourseChange			

Picture3. Functions and logical items

You can open signal condition and value editing window by double clicking on a parameter item from the list.



Picture4. Signal value and conditions

Functions are determined by setting numerical value, picking it from the list or picking from check box. Each logical item is dedicated to only one particular function. Logical item consists of parameter values and signal conditions (picture4.). Maximum items count is 84. However, logical unit count is unlimited for each function, but it must not exceed 84 in total. By clicking check box toggle your desired signal state (picture4.).



3.2.3. Function signals

Signal name	Signal description
Reset	Turn on temporarily after the system is restarted to indicate the event
Modem on	Modem of the device is enabled
IN1 – motion	Virtual input, used for motion detection
IN6	Virtual programmable input
Reserved	Reserved for future
System time registered	The device has turned UTC time internally from GPS or internet
Reserved	Reserved for future
Poor GPS signal	GPS signal does not meet the minimum requirements according to “F_GpsQualityMaxHdop” and “F_GpsQualityMinSat”
GSM jamming	GSM/DCS jammer is detected and it is disturbing normal use of GSM/DCS service
Roaming	Device is registered to a roaming network
GSM registered	Device is registered to any network
GPRS registered	Device is registered to GPRS data services
Internet active	Device is connected to internet
Preferred operator active	Device is registered to an operator from the preferred list
GPS speed present	GPS speed detection over 10km/h
SIM card ok	SIM card is inserted and PIN code removed
IN2	Physical – digital input
IN3	Physical – digital input
IN4	Physical – digital input
IN5	Physical – digital input
IN7 – engine on	Virtual input, battery charging detected
IN8	Virtual programmable input
One hour tick	Every hour for 10 minutes period
Six hour tick	Every six hours for 10 minutes period
Stack size threshold reached	There is more data in stack than allowed
Voice call	Voice call detected, settings locked for 30 minutes
Data call	Data call detected, settings locked for 30 minutes
Static signal1	General first static signal
Static signal2	General second static signal
Timer1	Special structure for internal timer signal
IbuttonPresent	“Dallas key” detected
Reserved	Special structure for internal timer signal

Table1. Signal descriptions

3.2.4. Functions

Functions name	Description/value expression
1.1 F_ModemPower	GSM modem power mode (on/off)
1.2 F_GpsPower	GPS device power mode (on/sleep)
2.1 F_InternetConnection	Create new internet connection (PDP context*), [permit/ban]
2.2 F_ServerConnection	Controls connection to server (connect/disconnect after 10 minutes)
2.3 F_DataSendPeriod	Period in which data is sent to server (automatic/custom)
2.4 F_DataSendOnInputsChange	Mask of inputs which may generate data transmission without waiting period timeout (tick a check-box to select desired input)
2.5 F_BroadcastMessagesPeriod	Reserved. Will be able in near future
3.1 F_GpsQualityMaxHdop	Maximum HDOP* of position to accept it to read (Recommended value – 35)
3.2 F_GpsQualityMinSat	Minimum satellites count for acceptance to read it
3.3 F_GpsReadPeriod	Period in which coordinates are read from GPS and put to internal track filter (never/value=seconds)
3.4 F_MaxTimeBetweenTwoGpsPoints	Maximum time between two fixed points (never/value=seconds)
3.5 F_GpsCourseChangeFix	Minimum course change for device to fixate it (value expressed in degrees)
3.6 F_GpsSpeedChangeFix	Fixation of vehicles speed difference from the last set value (expressed in km/h)
3.7 F_InputsChangeFix	Registers change of selected input state (tick a check-box to select desired input)
4.1 F_Dataset7_Mask1	Selected data will be included into the data packet (see annex 1)
4.2 F_Dataset7_Mask2	Selected FMS-CAN (J1939)* data will be included into the data packet (see annex 2)
4.3 F_Dataset7_Mask3	Selected data will be included into the data packet (see annex 3)
5.1 F_GeneralBitConfig	General bit configuration (tick a check-box to select desired function)
5.2 F_VibrationThreshold	Vibration (IN1) threshold (if value > selected threshold, IN1-motion=1). Used for detecting motion, recommended value - 200

5.3 F_NotDeliveredDataThreshold	Stack size threshold to generate signal “Stack size threshold reached”. Value expressed in bytes.
5.4 F_In8VoltageThreshold	Power supply voltage threshold. Expressed in volts (if value > threshold, IN8=1)
5.5 F_In6VoltageThreshold	ADC3 voltage threshold. Expressed in volts (if value > threshold, IN6=1)
5.6 F_FrequencyCounterSelect	Input mask for counter – frequency mode (tick a check-box to select desired input mode). Used for sensors, to work in counter or frequency mode
5.7 F_CanFunctionSelect	Selects CAN function. Enables CAN bus reading. Possible values: J1939-FMS; J1939 OBDII*; FMS ACK; FMS request;
5.8 F_EIA485FunctionSelect	RS485* function select. Enables RS485 input reading. Used for LLS*sensors and J1708*
5.9 F_RS232FunctionSelect	Reserved. Will be able in near future.
5.a F_NewConexionsToInternetLimiter	Limits next possible connection to internet (value expressed in seconds)
5.b F_Timer1	Special structure for internal timer signal
5.c F_Timer1_GMT	Used to set GMT value.
5.d F_Timer2_Control	Special structure for internal timer signal
5.e F_Timer2_Threshold	Time threshold expressed in seconds. Used with 5.d function
5.f F_OUT1_Control	Function for OUT1 output control. Works in three modes: off1 – output disabled, but can be controlled with GPRS commands; on (minus) – enabled; off2 – disabled;
5.g F_OUT2_Control	Function for OUT2 output control. Works in three modes: off1 – output disabled, but can be controlled with GPRS commands; on (minus) – enabled; off2 – disabled;
6.1 F_Dataset1_Timeout	Not used for wialon
6.2 F_Dataset2_Timeout	Not used for wialon
6.3 F_Dataset3_Timeout	Not used for wialon
6.4 F_Dataset4_Timeout	Not used for wialon
6.5 F_Dataset51_Timeout	Not used for wialon
6.6 F_Dataset8_Timeout	Not used for wialon
6.7 F_Sms_TrigerMaskRising	Sms mask value. Sending sms when changing from 0 to 1 (tick a check-box to select desired input)
6.8 F_Sms_TrigerMask_Faling	Sms mask value. Sending sms when



	changing from 1 to 0 (tick a check-box to select desired input)
6.9 F Sms NextSmsTimeout	Next sms timeout. Expressed in seconds
6.a F Sms MaxSmsPerHour	Maximum sms per hour
Reserved_43.....Reserved_63	Reserved for future

Table2. Function descriptions

- HDOP – horizontal dilution of precision. This gives an indication of precision of the position fix from GPS, based on the satellites it is currently using and its geometry.
- PDP context – packet data protocol context is a term used in the mobile wireless network indicating a logical association between an MS (mobile station) and PDN (Public data network) running across a GPRS network. The context defines aspects such as routing, qos (quality of service), security, billing etc.
- FMS-CAN (J1939) – “fleet management systems” interface is a standard interface to vehicle data of commercial vehicles. J1939 is a vehicle bus standard used for communication and diagnostics among vehicle components.
- OBD-II – on board diagnostics, is an automotive term, referring to a vehicles self-diagnostic and reporting capability. The OBD-II standard specifies the type of diagnostic connector and its pinout, the electrical signaling protocols available, and the messaging format.
- EIA-485, also known as TIA/EIA-485 or RS-485, is a standard defining the electrical characteristics of drivers and receivers for use in balanced digital multipoint systems.
- J1708 - standard used for serial communications between ECU (Electronic control unit) on a heavy duty vehicle and also between a computer and a vehicle.
- LLS – Liquid level sensor

4. Connecting “Vepamon” LLS fuel level sensors to FM Blue device

Sensors can be connected in two modes:

- 1) Frequency
- 2) Analog

You can connect one or two sensors at a time to one FM light device. Sensors signal ground wire connects to the same pin with devices ground (-) wire.

4.1. Frequency mode.

4.1.1. Connecting one LLS sensor.




Fig. 1. One sensors connection to FM blue+ using frequency mode.

4.1.2. Connecting two LLS sensors.



Fig. 2. Two sensors connection to FM blue+ using frequency mode.

4.2. Analog mode

4.2.1. Connecting one LLS sensor



Fig. 3. One sensors connection to FM blue+ using analog mode.

4.2.2. Connecting two LLS sensors



Fig. 4. Two sensors connection to FM blue+ using analog mode.