



PHONES

(044) 360-7-130
 (050) 336-0-130
 (063) 788-0-130
 (067) 233-0-130
 (068) 282-0-130

130 Internet store of autogoods

COM.UA



ICQ
 294-0-130
 597-0-130

SKYPE
 km-130

CAR RECEIVERS — Receivers • Media receivers and stations • Native receivers • CD/DVD changers • FM-modulators/USB adapters • Flash memory • Facia plates and adapters • Antennas • Accessories |
 CAR AUDIO — Car audio speakers • Amplifiers • Subwoofers • Processors • Crossovers • Headphones • Accessories | TRIP COMPUTERS — Universal computers • Model computers • Accessories |
 GPS NAVIGATORS — Portable GPS • Built-in GPS • GPS modules • GPS trackers • Antennas for GPS navigators • Accessories | VIDEO — DVR • TV sets and monitors • Car TV tuners • Cameras • Videomodules
 • Transcoders • Car TV antennas • Accessories | SECURITY SYSTEMS — Car alarms • Bike alarms • Mechanical blockers • Immobilizers • Sensors • Accessories | OPTIC AND LIGHT — Xenon • Bixenon • Lamps
 • LED • Stroboscopes • Optic and Headlights • Washers • Light, rain sensors • Accessories | PARKTRONICS AND MIRRORS — Rear parktronic • Front parktronic • Combined parktronic • Rear-view mirrors
 • Accessories | HEATING AND COOLING — Seat heaters • Mirrors heaters • Screen-wipers heaters • Engine heaters • Auto-refrigerators • Air conditioning units • Accessories | TUNING — Vibro-isolation
 • Noise-isolation • Tint films • Accessories | ACCESSORIES — Radar-detectors • Handsfree, Bluetooth • Windowlifters • Compressors • Beeps, loudspeakers • Measuring instruments • Cleaners • Carsits
 • Miscellaneous | MOUNTING — Installation kits • Upholstery • Grilles • Tubes • Cable and wire • Tools • Miscellaneous | POWER — Batteries • Converters • Start-charging equipment • Capacitors
 • Accessories | MARINE AUDIO AND ELECTRONICS — Marine receivers • Marine audio speakers • Marine subwoofers • Marine amplifiers • Accessories | CAR CARE PRODUCTS — Additives • Washer fluid •
 Care accessories • Car polish • Flavors • Adhesives and sealants | LIQUID AND OIL — Motor oil • Transmission oil • Brake fluid • Antifreeze • Technical lubricant



In store "130" you can find and buy almost all necessary goods for your auto in Kyiv and other cities, delivery by ground and postal services. Our experienced consultants will provide you with exhaustive information and help you to chose the very particular thing. We are waiting for you at the address

<http://130.com.ua>



Germany

Turbo 3 Power PRO
CENTRIFUGAL 2-MOTOR • VACUUM CLEANER



Bedienungsanleitung

Instruction

Руководство по эксплуатации

ISO 9001:2008
Certified
Quality



Description

1. Contacts of the turbo brush
2. Turbo motor-brush
3. Air inlet
4. Dust-box housing
5. Centrifugal filter
6. Dust-box lock button
7. ON/OFF Switch
8. motor housing
9. Power cord
10. Power plug
11. Adapter
12. Small crevice nozzle
13. Brush nozzle
14. Connecting contacts
15. Filter

Safety instructions

Always observe following safety instructions! This will prevent injuries and damage. Read this instruction carefully before using the vacuum cleaner. Save the instruction as a reference book.

- This model is intended only for dry cleaning. Do not use it to pick up water or other liquids.
- Do not immerse it into water.
- Do not use the vacuum cleaner to pick up flammable or combustible liquids (gasoline, cleaning fluids, perfumes, etc.), or use in areas where they maybe present.
- Do not pick up burning or smoking cigarettes, matches or hot ashes.
- Use only original manufacturers accessories.
- This appliance is not intended for

use by young children as a toy or by infirm people without supervision. Never leave an appliance unattended when it is switched on.

- Keep far from your face and eyes.
- Do not use the vacuum cleaner when some of its openings are blocked.
- Clean the brushes and filters of dust, hair and other things which obstruct normal air intake. This might cause malfunction or damage the device.
- Do not use without filters.
- To disconnect the appliance do not pull the cord, always take up the plug which is inserted into car cigarette lighter.
- While using make sure that the cord is not pressed between the car doors or windows.
- Do not use the appliance if it is damaged. Apply to the dealer or authorized service centres for repair.
- Always switch off and unplug the vacuum cleaner after using, while cleaning and while changing the nozzles.
- Keep away from children. Before using, check if the vacuum cleaner or the accessories are damaged.

Electrical safety

- The appliance should be supplied from car on-board power system of 12V with grounded minus.

ENGLISH

- Do not connect to the voltage with grounded plus or other voltage.
- Car cigarette lighter can be incurrent if the key is out of ignition. In this case see your car manual.
- Strip contacts voltage is not more than 12V that is it safe for the user.
- For short circuit protection there is a 10A thermal fuse mounted in the plug. To change it twist the central plug cape off, change the fuse and twist the cap on.

Usage of the car vacuum cleaner

Important!

- The best results can be achieved only when the filters are clean and the centrifugal filter is empty.
- Before using make sure that the dust box housing is correctly connected to the motor housing.
- Do not use the vacuum cleaner, for over 30 minutes, because the charge of the car battery maybe lowered. Unwind the power cord and put the plug into the car cigarette lighter.

Choosing the cleaning-nozzle

Choose and connect the required nozzle to suction inlet according to dirt and surface:

1. Without nozzle
clean normally dirty,
textile surfaces.

2. Turbo-motor-brush
clean extremely dirty surfaces,
hair etc. from textile surfaces.
3. Brush nozzle
Clean hard surfaces.
4. Crevice nozzle
Clean hard to reach holes and
crevices.

Using the turbo motor-brush

- Set the turbo brush into the suction inlet up to the stop.
- Turn the vacuum cleaner on with the switch. At the same time the cylindrical brush drive motor will switch on. Cylindrical brush is effective by sweeping small rubbish out of carpet surfaces.
- After using turn the vacuum cleaner off with the switch.

Using the brush nozzle

- Put the nozzle into the suction inlet.

Crevice nozzle

- Insert the crevice nozzle into the suction inlet.

After Cleaning

Turn on the vacuum cleaner with the switch after using switch off the vacuum cleaner and take off the plug from cigarette car lighter. Remove the rubbish and dust from the Turbo-Motor-brush, woven filter and centrifugal filter.

Rubbish and dust removal

- We recommend removing

rubbish and dust each time after the car cleaning.

- Turn off the vacuum cleaner with the switch and take out the plug from the car cigarette lighter.
- Hold the vacuum cleaner by the handle with the motor housing upwards.
- Press the dust-box housing lock button and disconnect the dust-box housing from the motor housing.
- Take out the woven filter set from the centrifugal filter and remove rubbish and dust.
- Take out the centrifugal filter set from the dust box housing.
- Turn down the centrifugal filter and remove the collected rubbish and dust.

Attention Do not wash the dust-box housing with water, only dry cleaning is possible.

- Take off an clean from rubbish the woven filter.
- Take off and clean the centrifugal filter.
- Insert the woven filter into the centrifugal filter and both into the dust-box housing.
- Put the dust-box housing back to the motor housing. To do this, connect the contacts at a small angle in order to connect the lock, simultaneously press the dust-box housing lock button and fully close the dust-box. Release the lock button ("click").

Cleaning of the filter set

Keep the filters clean as this ensures the vacuum cleaner efficiency. Clean the filters 3, 4 or more times a year. The filters are intended for multiple cleaning.

- Take off the dust-box housing and take out the filters.
- Clean the filters from dust and wash it with warm water.
- Dry the filters before inserting them into the dust-box.

Attention

- Do not wash the filters in the dishwashing machine.
- Do not dry the filters with hair-dryer or other heated appliances.

Cleaning of the turbo brush

Take off the turbo brush and remove hairs or threads from the cylindrical brush.

Case of the vacuum cleaner

- Clean the case with a wet cloth.
- Do not permit liquid to enter the device.
- Do not use solvents or abrasive substances for cleaning.

Storage

After using take off the nozzle from the suction inlet. Clean and store the device together with the accessories and this instruction manual in the original storage case.

Technical characteristics

Power supply: DC	12V
Power consumption:	105 W
Cord length:	3,6m



Only for EC-Countries

After the implementation of the European Directive 2002/96/EU in the national legal system, the following applies: Electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic devices at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. This symbol on the product, the instruction manual or the package indicates that a product is subject to these regulations. By recycling, reusing the materials or other forms of utilising old devices, you are making an important contribution to protecting our environment.



EU Statement of conformity

Hereby we declare that this commodity corresponds to the following EC directives for general requirements of safety and health

- Electromagnetic compatibility 2004/108/EC.