



PHONES

(044) 360-7-130
(050) 336-0-130
(063) 788-0-130
(067) 233-0-130
(068) 282-0-130

130 Internet store of autogoods

COM.UA



ICQ
294-0-130
597-0-130

SKYPE
km-130

CAR RECEIVERS — Receivers • Media receivers and stations • Native receivers • CD/DVD changers • FM-modulators/USB adapters • Flash memory • Facia plates and adapters • Antennas • Accessories |
CAR AUDIO — Car audio speakers • Amplifiers • Subwoofers • Processors • Crossovers • Headphones • Accessories | TRIP COMPUTERS — Universal computers • Model computers • Accessories |
GPS NAVIGATORS — Portable GPS • Built-in GPS • GPS modules • GPS trackers • Antennas for GPS navigators • Accessories | VIDEO — DVR • TV sets and monitors • Car TV tuners • Cameras • Videomodules
• Transcoders • Car TV antennas • Accessories | SECURITY SYSTEMS — Car alarms • Bike alarms • Mechanical blockers • Immobilizers • Sensors • Accessories | OPTIC AND LIGHT — Xenon • Bixenon • Lamps
• LED • Stroboscopes • Optic and Headlights • Washers • Light, rain sensors • Accessories | PARKTRONICS AND MIRRORS — Rear parktronic • Front parktronic • Combined parktronic • Rear-view mirrors
• Accessories | HEATING AND COOLING — Seat heaters • Mirrors heaters • Screen-wipers heaters • Engine heaters • Auto-refrigerators • Air conditioning units • Accessories | TUNING — Vibro-isolation
• Noise-isolation • Tint films • Accessories | ACCESSORIES — Radar-detectors • Handsfree, Bluetooth • Windowlifters • Compressors • Beeps, loudspeakers • Measuring instruments • Cleaners • Carsits
• Miscellaneous | MOUNTING — Installation kits • Upholstery • Grilles • Tubes • Cable and wire • Tools • Miscellaneous | POWER — Batteries • Converters • Start-charging equipment • Capacitors
• Accessories | MARINE AUDIO AND ELECTRONICS — Marine receivers • Marine audio speakers • Marine subwoofers • Marine amplifiers • Accessories | CAR CARE PRODUCTS — Additives • Washer fluid •
Care accessories • Car polish • Flavors • Adhesives and sealants | LIQUID AND OIL — Motor oil • Transmission oil • Brake fluid • Antifreeze • Technical lubricant



In store "130" you can find and buy almost all necessary goods for your auto in Kyiv and other cities, delivery by ground and postal services. Our experienced consultants will provide you with exhaustive information and help you to chose the very particular thing. We are waiting for you at the address

<http://130.com.ua>



Автопылесос с влажной уборкой

Меры предосторожности:

1. Прочитайте инструкцию и следуйте ее указаниям.
2. При работе не подносите пылесос близко к глазам или ушам.
3. Убирайте неработающий пылесос. Храните его в сухом недоступном для детей месте.
4. Не работайте без фильтра, немедленно ремонтируйте или заменяйте поврежденный фильтр.
5. Не собирайте пылесосом горячие материалы, например, горячие окурки сигарет.
6. Содержите пылесос в чистоте для лучшей работы.
7. При работе автопылесоса не заводите двигатель автомобиля.
8. Не работайте в загазованной или взрывоопасной атмосфере. Двигатель автопылесоса обычно создает искры, которые могут вызвать воспламенение.
9. Пылесос способен работать до получения без заметной разрядки исправной заряженной батареи. Работающий двигатель автомобиля сокращает срок службы автопылесоса.
10. При хранении обмотайте провод вокруг рукоятки пылесоса (Фиг.1). **Включение:** Автопылесос включается сдвигом выключателя по направлению "носика" автопылесоса.

Сухая уборка:

1. Вставьте штекер в гнездо прикуривателя и включите автопылесос.
1. Аля лучшей уборки поддерживайте фильтр пылесоса в чистоте.
2. При чистке ворсовых ковровых покрытий перемещайте "носик" пылесоса в направлении, показанном на фиг. 2.

Влажная уборка.

При уборке воды и влажных частиц держите пылесос в вертикальном или близком к нему положении. Уровень собранной воды можно наблюдать через прозрачную стенку контейнера для мусора. Когда уровень воды достигнет кромки внутренней возвратной трубы, уборку следует прекратить. Возобновлять уборку можно, только опорожнив контейнер.

Щелевая насадка:

Для уборки трудно доступных мест используется щелевая насадка, которую надо вставить в "носик" пылесоса, как показано на фиг.3.

Удаление мусора из контейнера и чистка фильтра:

1. Для удаления мусора из контейнера, следует нажать клавишу и отделить контейнер от пылесоса (фиг. 4).
2. Как показано на фиг. 5 и 6, выньте фильтр и пылезащитный экран. Затем очистите контейнер от грязи.
3. Для очистки фильтра от пыли используйте щетку (фиг. 7).

SAFETY RULES:

1. Read and follow all instructions.
2. Do not place bow inlet or outlet of vacuum cleaner near eyes or ears while operating.
3. Do not expose the unit to rain.
4. Store idle tools. When not in use, the unit should be stored in a dry, high or locked-up place-out of reach of children.
5. Do not operate without filter bag in place repair or replace a damaged bag promptly.
6. Do not pick up burning materials such as lit cigarette butts.
7. Do not run vehicle's engine while cleaning.
8. Maintain tool with care. Keep bowl and fan area clean for best and safest performance, follow instructions for proper maintenance.
9. Do not operate portable electric tools in a gaseous or explosive atmosphere. Motors in these tools normally spark, and the sparks might ignite fumes.
10. You can clean for periods up to 1/2 hour long without noticeably affecting the power of a normally charged vehicle battery in good condition. Running the vehicle engine while cleaning is not recommended and may shorten tool life.
11. For storage, wind the cord around the tool in the handle (fig. 1).



FIG.1




FIG.2



FIG.3

SWITCH OPERATION

The unit is turned on by pushing the slide button toward the nozzle end of the vac.

The tool will remain "ON" until the slide button is pulled backward to turn it "OFF".

VACUUMING INSTRUCTIONS

1. Push vacuum plug into cigarette lighter socket, and push slide switch forward to start vacuuming. Note: if vac fails to operate, clean any burned tobacco tar from lighter socket with a small wooden stick.
2. For the most efficient vacuuming, keep the filter bag clean.
3. When cleaning high-loop, pile rugs, pull nozzle in the direction shown in (Fig. 2) to avoid snagging the nozzle in the pile.



FIG.4

CREVICE TOOL

The crevice tool for use in hard-to-get-to areas and surfaces is pushed into the collector bowl as shown in figure (Fig. 3) **DIRT**

REMOVAL & FILTER BAG CLEANING

1. To remove dirt from the collector bowl, hold unit as shown in figure (Fig. 4)
2. Depress latch and swing collector bowl away and down from unit handle.
3. Place fingers into bowl and remove filter bag from collector bowl (Fig. 5)



FIG.5

4. Empty dirt from collector bowl. (Fig. 6)
5. Clean filter bag by:
 - a. Brushing the dirt off the bag. (Fig. 7)
 - b. Thoroughly shaking the bag clean into the waste can, or
 - c. Hand washing the filter bag with a mild detergent or dish washing soap. After washing, put a paper towel into the filter bag and squeeze the filter to remove the retained moisture. Be sure the filter bag is dry before replacing. (Fig. 8)
6. Reassemble bowl to unit (Fig. 9). by placing rear lower edge of bowl against lower ledge on front of unit. Line up so that front of unit fits into bowl, then snap together so that upper latch snaps into place holding bowl to unit.

CLEANER PLASTIC PARTS

Use only mild soap and a rag dampened with hot water to clean the plastic parts.

Avoid all other type of detergents cleaners, or solvent which might contain chemicals that could seriously damage the plastic.

Thank you very much



FIG. 6



FIG. 7



FIG. 8



FIG. 9