

PHONES (044) 360-7-130 (050) 336-0-130 (063) 788-0-130 (067) 233-0-130 (068) 282-0-130

130 Internet store of autogoods



294-0-130 597-0-130

> SKYPE km-130

CAR RECEIVERS — Receivers • Media receivers and stations • Native receivers • CD/DVD changers • FM-modulators/USB adapters • Flash memory • Facia plates and adapters • Antennas • Accessories |

CAR AUDIO — Car audio speakers • Amplifiers • Subwoofers • Processors • Crossovers • Headphones • Accessories | TRIP COMPUTERS — Universal computers • Model computers • Accessories |

GPS NAVIGATORS — Portable GPS • Built-in GPS • GPS modules • GPS trackers • Antennas for GPS navigators • Accessories | VIDEO — DVR • TV sets and monitors • Car TV tuners • Cameras • Videomodules
• Transcoders • Car TV antennas • Accessories | SECURITY SYSTEMS — Car alarms • Bike alarms • Mechanical blockers • Immobilizers • Sensors • Accessories | OPTIC AND LIGHT — Xenon • Bixenon • Lamps
• LED • Stroboscopes • Optic and Headlights • Washers • Light, rain sensors • Accessories | PARKTRONICS AND MIRRORS — Rear parktronics • Combined parktronics • Rear-view mirrors
• Accessories | HEATING AND COOLING — Seat heaters • Mirrors heaters • Screen-wipers heaters • Engine heaters • Auto-refrigerators • Air conditioning units • Accessories | TUNING — Vibro-isolation
• Noise-isolation • Tint films • Accessories | ACCESSORIES — Radar-detectors • Handsfree, Bluetooth • Windowlifters • Compressors • Beeps, loudspeakers • Measuring instruments • Cleaners • Carsits
• Miscellaneous | MOUNTING — Installation kits • Upholstery • Grilles • Tubes • Cable and wire • Tools • Miscellaneous | POWER — Batteries • Converters • Start-charging equipment • Capacitors
• Accessories | MARINE AUDIO AND ELECTRONICS — Marine receivers • Marine audio speakers • Marine audios of • Brake fluid • Antifreeze • Technical lubricant



In store "130" you can find and buy almost all necessary goods for your auto in Kyiv and other cities, delivery by ground and postal services. Our experienced consultants will provide you with exhaustive information and help you to chose the very particular thing. We are waiting for you at the address

http://130.com.ua



Bedienungsanleitung

Achtung!

- 1. Bitte lesen Sie die vorliegende Anleitung sehr aufmerksam, um eine sichere Handhabung zu gewahrleisten.
- 2. Das Gerat nur mit Handschuhen benutzen. Der Kompressor kann sich stark erwarmen. Die Nichtverwendung von Handschuhen kann zu Verbrennungen ftihren.

www.alcamobil.de

English

READ CAREFULLY!

Unless direction are followed, physical injury or property damage may result. When using the compressor, never leave it unattented.

- 1. Power required: 12 volts 30 amps. D.C.
- 2. This compressor is designed for occasional use only. Operation over an extended period of time will overheat the unit and damage the compressor. A sluggish operation of the compressor or if the exposed metal fittings get too warm to the touch should indicate to you that the unit has been operating too long and is overheating. When this occurs stop, the unit immediately and let it cool for approximately 30 minutes before resuming operation.
- 3. You may use 12 volt battery charger to power this compressor, but it must be rated at 30 amps or more to avoid damage to the compressor and for the charger
- 4. Do not use air inflator on high pressure tires such a those used on large trucks.

TO INFLATE TIRES

1. Place connector on input valve stem (Fig. 1) and push down. Close thumb latch connector (Fig. 2).

Caution! Make sure the connector always touches the core of tire valve stem.







Fig. 1

Fig. 2

Fig. 3

- 2. Connect clips to battery poles (Fig. 3). _ of correct poles. Then set compressor ON/OFF switch to "ON" position.
- 3. When proper pressure is reached, set ON/OFF switch to "OFF" position, unplug the clips and remove connector.

English

FOR INFLATABLES

- 1. Select the suitable adapter and insert it into the connector (Fig. 4).
- 2. Check our typical inflation pressure chart.

This chart is for reference only and you should consult your owner's manual for a more exact pressure rating.

- 3. Insert adapter into article to be inflated (Fig. 5)
- 4. Connect clips to battery poles (Fig. 3). Turn on switch.
- 5. When proper pressure is reached, turn off switch, unplug the clips.
- 6. Remove adapter from inflated article and remove adapter from connector.







TYPICAL INFLATION PRESSURE

Avoid overrating. NEVER EXCEED RECOMMENDED PRESSURE. The item being inflated may burst and cause serious injury.

Auto-Tire	PSI	Bicycle Tires	PS I
	24 -32		35-40
Please consult your owner's manual more exact pressure rating.	nual for a	Other Inflatables Football	PSI
		Basketball Volleyball	13 9 5
Shock-Absorber	PSI	Lawn-Tractor Tire	22
Normal Load	40	Boat (2 man)	solid
Heavy Load	90	Mettress	solid

Caution! Soft inflatable material items will not have existing pressure reading. You must be careful not over-inflate.



English

TROUBLE SHOOTING

Compressor does not start/blows fuses

- 1. Check the right connection of the clips to bettery poles.
- 2. Check vehicle lighter fuse. Should be 30 amps minimum.

Compressor runs but doesn't inflate

- 1. Be sure the connetor always touches the core of the valve stem.
- 2. Check article for leaks.
- 3. Check hose for breaks and leaks at fittings.

Compressor runs slowly

- 1. Overheated from excessive use. Shut it off and let it cool for 30 minute.
- 2. Voltage too low. Check condition of battery.

Caution!

- 1. Do not over inflate items beyond their needs. Most car tires will inflate properly between 24-32 PSI depending upon tire the tire. Some truck and racing bicycle tires require pressure in excess of 40 PSI. Other bicycle tires require substantially lower pressures.
- 2. Keep out of reach of children.
- 3. Do not leave unattended.

Item may be modified according technical progress.





Die Qualittitsmarke aus Deutschland fur Ihr Automobil.

Alca mobil auto accessories gmbh

Kurzer Weg 1 D - 15859 Storkow

Tel: +49 (0) 33678 678 0 Fax: +49 (0) 33678 610 44 Internet: www.alcamobil.de

