



PHONES

0 (800) 800 130
(050) 462 0 130
(063) 462 0 130
(067) 462 0 130

130
COM.UA

Internet store of
autogoods



SKYPE

km-130

CAR RECEIVERS — Receivers • Media receivers and stations • Native receivers • CD/DVD changers • FM-modulators/USB adapters • Flash memory • Facia plates and adapters • Antennas • Accessories |
CAR AUDIO — Car audio speakers • Amplifiers • Subwoofers • Processors • Crossovers • Headphones • Accessories | TRIP COMPUTERS — Universal computers • Model computers • Accessories |
GPS NAVIGATORS — Portable GPS • Built-in GPS • GPS modules • GPS trackers • Antennas for GPS navigators • Accessories | VIDEO — DVR • TV sets and monitors • Car TV tuners • Cameras • Videomodules
• Transcoders • Car TV antennas • Accessories | SECURITY SYSTEMS — Car alarms • Bike alarms • Mechanical blockers • Immobilizers • Sensors • Accessories | OPTIC AND LIGHT — Xenon • Bixenon • Lamps
• LED • Stroboscopes • Optic and Headlights • Washers • Light, rain sensors • Accessories | PARKTRONICS AND MIRRORS — Rear parktronic • Front parktronic • Combined parktronic • Rear-view mirrors
• Accessories | HEATING AND COOLING — Seat heaters • Mirrors heaters • Screen-wipers heaters • Engine heaters • Auto-refrigerators • Air conditioning units • Accessories | TUNING — Vibro-isolation
• Noise-isolation • Tint films • Accessories | ACCESSORIES — Radar-detectors • Handsfree, Bluetooth • Windowlifters • Compressors • Beeps, loudspeakers • Measuring instruments • Cleaners • Car seats
• Miscellaneous | MOUNTING — Installation kits • Upholstery • Grilles • Tubes • Cable and wire • Tools • Miscellaneous | POWER — Batteries • Converters • Start-charging equipment • Capacitors
• Accessories | MARINE AUDIO AND ELECTRONICS — Marine receivers • Marine audio speakers • Marine subwoofers • Marine amplifiers • Accessories | CAR CARE PRODUCTS — Additives • Washer fluid •
Care accessories • Car polish • Flavors • Adhesives and sealants | LIQUID AND OIL — Motor oil • Transmission oil • Brake fluid • Antifreeze • Technical lubricant




In store "130" you can find and buy almost all necessary goods for your auto in Kyiv and other cities, delivery by ground and postal services. Our experienced consultants will provide you with exhaustive information and help you to chose the very particular thing. We are waiting for you at the address

<https://130.com.ua>



MVH-S110UI MVH-S110UIG MVH-S110UB MVH-S110UBG

Quick start guide
Guide de démarrage rapide
Guida rapida all'uso
Guia de iniciación rápida
Schnelstartanleitung
Snelstartgids




Declaration of Conformity with regard to the Radio Equipment Directive 2014/53/EU
Manufacturer: Pioneer Corporation
EU Representative's Importer: Pioneer Europe NV
Pioneer Europe NV
Koningin Beatrixlaan 1, 9120 Melle, Belgium
Tel: +32 (0)2 261 1111
www.pioneer-car.eu


English
This guide is intended to guide you through the basic functions of this unit. For details, please refer to the Operation manual stored on the website.
<https://www.pioneer-car.eu/en/>

Before You Start
Thank you for purchasing this PIONEER product. Please read this guide before using this product. It is especially important that you read and observe **WARNINGS** and **CAUTIONS** in this guide. Please keep the guide in a safe and accessible place for future reference.

Connections
! WARNING
When installing this unit in a vehicle without an ACC (accessory) position on the ignition switch, failure to connect the red cable to the terminal that detects the operation of the ignition key may result in battery drain.



Power cord
Use a fuse of the rating prescribed. Never wire the negative speaker cable directly to ground. Never band together negative cables of multiple speakers.



Basic operation
MVH-S110UI/S110UIG/S110UI/S110UB/S110UBG/S110UBA/S110UBW
SRC (source)/OFF
M.C. (multi-control) dial
DISP (display)
Display window
AUX input jack (3.5 mm stereo jack)
USB port

Frequently used operations

Purpose	Operation
Turn on the power	Press SRC/OFF to turn on the power. Press and hold SRC/OFF to turn off the power.
Adjust the volume	Turn the M.C. dial.
Select a source	Press SRC/OFF repeatedly.
Change the display information	Press DISP repeatedly.
Return to the previous display/list	Press BAND/ .
Return to the normal display from the menu	Press and hold BAND/ .
Change the display brightness	Press and hold BAND/ .
Boost the bass level	Press BASS . You can select the bass level in [BASS BOOST].

Setup operation

Menu Item	Description
LANGUAGE	Select the language to display the text information from a compressed audio file. [ENG] (English), [PRC] (Russian), [TUR] (Turkish)
CLOCK SET	Set the clock. 1 Turn the M.C. dial to adjust the hour, then press to confirm. The indicator moves to the minute setting automatically. 2 Turn the M.C. dial to adjust the minute, then press to confirm.
FM STEP	Select the FM tuning step from 100 kHz or 50 kHz. [100], [50]

Tuner operation
Receiving preset stations
1 Press **SRC/OFF** to select [RADIO].
2 Press **BAND/** to select the band. [FM1] [FM2] [FM3] [MW]/[LW]
3 Press a number button (1/1A to 6/6A).

USB/iPod/AUX operation
NOTE
MVH-S110UB/S110UBG/S110UBA/S110UBW is not compatible with Apple's devices.
USB/iPod
1 Open the USB port cover.
2 Plug in the USB device/iPod using an appropriate cable.


Making a connection with Pioneer ARC APP
Pioneer's Advanced app converts your compatible smartphone into a powerful touchscreen remote control.
Download Now
Pioneer ARC

When making a connection with an iPhone
1 Connect this unit with the iPhone via USB.
2 Press **SRC/OFF** to select any source.
3 Press and hold the **M.C.** dial. Pioneer ARC APP on the iPhone starts.
NOTE
If the connection fails, launch Pioneer ARC APP on the iPhone.
Listening to Spotify®
(Only compatible with Spotify installed on iPhone)
NOTE
MVH-S110UB/S110UBG/S110UBA/S110UBW is not compatible with Apple devices.
Update the firmware of the Spotify application to the latest version before use. Before you start, connect this unit with the mobile device via USB (iPhone only).
1 Press **SRC/OFF** to select [SPOTIFY].
2 Launch the Spotify application on the mobile device and start playback.

Avant de commencer
Nécessaire une utilisation correcte, veuillez lire attentivement ce guide avant d'utiliser ce produit. Il est particulièrement important que vous lisiez et respectiez les indications **ATTENTION** et **PRÉCAUTION** de ce guide. Veuillez conserver le guide dans un endroit sûr et accessible pour toute consultation ultérieure.
<https://www.pioneer-car.eu/en/>

Si vous rencontrez des problèmes
En cas d'anomalie, veuillez contacter votre revendeur ou le centre d'entretien agréé par PIONEER le plus proche.

Raccourcissements
! IMPORTANT
Lorsque vous installez cet appareil dans un véhicule sans position ACC (accessory) sur le contact, si vous omettez de brancher le câble rouge à la borne qui détecte le fonctionnement de la clé de contact, vous risquez d'entraîner une fuite de la batterie.



Amplificateur de puissance (vendu séparément)
Effectuez les raccourcissements si vous utilisez l'amplificateur optionnel.
Installation
! Important
Vérifiez tous les raccourcissements et les systèmes avant l'installation finale.

Installation pour montage DIN
1 Insérez le manchon de montage fourni dans le tableau de bord.
2 Fixez le manchon de montage à l'aide d'un tournevis pour plier les languettes métalliques (90°) et les mettre en place.
Retrait de l'appareil (installé avec le manchon de montage fourni)
1 Retirez l'anneau de garniture.
2 Retirez l'appareil du tableau de bord.

Fonctionnement de base
MVH-S110UI/S110UIG/S110UI/S110UB/S110UBG/S110UBA/S110UBW
SRC (source)/OFF
Molette M.C. (multi-contrôle)
DISP (affichage)
Fenêtre d'affichage
Prise d'entrée AUX (prise stéréo 3,5 mm)
Port USBTouche de retrait

Opérations fréquemment utilisées

Objectif	Opération
Mettre l'appareil sous tension	Appuyez sur SRC/OFF pour mettre l'appareil sous tension. Appuyez longuement sur SRC/OFF pour mettre l'appareil hors tension.
Régler le volume	Tournez la molette M.C.
Sélectionner une source	Appuyez plusieurs fois sur SRC/OFF .
Modifier les informations d'affichage	Appuyez plusieurs fois sur DISP .
Revenir à l'affichage / à la liste précédente	Appuyez sur BAND/ .
Revenir à l'affichage normal à partir du menu	Appuyez longuement sur BAND/ .
Modifier la luminosité de l'affichage	Appuyez longuement sur BAND/ .
Augmenter le niveau des basses	Appuyez sur BASS . Vous pouvez sélectionner le niveau des basses dans [BASS BOOST].

Fonctionnement de la configuration
Lorsque vous appuyez sur le bouton de démarrage ON après avoir installé l'appareil, [SETUP :YES] apparaît sur l'affichage.
1 Appuyez sur la molette **M.C.**.
2 Tournez la molette **M.C.** pour sélectionner les options, puis appuyez pour valider. Pour passer à l'option de menu suivante, vous devez valider votre sélection.

Fonctionnement du synthoniseur
Réception des stations présélectionnées
1 Appuyez sur **SRC/OFF** pour sélectionner [RADIO].
2 Appuyez sur **BAND/** pour sélectionner la bande. [FM1] [FM2] [FM3] [MW]/[LW]
3 Appuyez sur l'une des touches numériques (1/A à 6/6A).

Fonctionnement de l'USB/iPod/AUX
REMARQUE
Le MVH-S110UB/S110UBG/S110UBA/S110UBW n'est pas compatible avec les périphériques Apple.
USB/iPod
1 Ouvrez le cache du port USB.
2 Raccordez le périphérique USB/iPod à l'aide d'un câble approprié.

Se connecter à Pioneer ARC APP
L'application Advanced de Pioneer transforme votre smartphone compatible en un télécommande à écran tactile puissante.
Téléchargez dès à présent
Pioneer ARC

Lorsque vous vous connectez à un périphérique Android
1 Entrez dans le menu SYSTEM (reportez-vous à la section « À propos du menu principal »).
2 Tournez la molette **M.C.** pour sélectionner [ANDROID WIRE], puis appuyez pour valider.
3 Tournez la molette **M.C.** pour sélectionner [APP CONTROL], puis appuyez pour valider.
4 Tournez la molette **M.C.** pour sélectionner [PAPP AUTO ON], puis appuyez pour valider.
5 Tournez la molette **M.C.** pour sélectionner [ON], puis appuyez pour valider.
6 Connectez cet appareil au périphérique via USB. Pioneer ARC APP sur le périphérique Android démarre automatiquement.

Lorsque vous vous connectez à un iPhone
1 Connectez cet appareil à l'iPhone via USB.
2 Appuyez sur **SRC/OFF** pour sélectionner une source.
3 Appuyez longuement sur la molette **M.C.** Pioneer ARC APP sur l'iPhone démarre.
REMARQUE
En cas d'échec de la connexion, lancez Pioneer ARC APP sur l'iPhone.
Écoute de Spotify®
(Compatible uniquement avec l'iPhone sur lequel Spotify est installé)
REMARQUE
Le MVH-S110UB/S110UBG/S110UBA/S110UBW n'est pas compatible avec les périphériques Apple.
Mettez à jour le microprogramme de l'application Spotify dans sa dernière version avant de l'utiliser. Avant de commencer, connectez cet appareil au périphérique mobile via USB (iPhone uniquement).
1 Appuyez sur **SRC/OFF** pour sélectionner [SPOTIFY].
2 Lancez l'application Spotify sur le périphérique mobile, puis démarrez la lecture.

