



0 (800) 800 130
(050) 462 0 130
(063) 462 0 130
(067) 462 0 130

130
COM.UA

Internet store of autogoods



km-130

CAR RECEIVERS — Receivers • Media receivers and stations • Native receivers • CD/DVD changers • FM-modulators/USB adapters • Flash memory • Face plates and adapters • Antennas • Accessories | CAR AUDIO — Car audio speakers • Amplifiers • Subwoofers • Processors • Crossovers • Headphones • Accessories | TRIP COMPUTERS — Universal computers • Model computers • Accessories | GPS NAVIGATORS — Portable GPS • Built-in GPS • GPS modules • GPS trackers • Antennas for GPS navigators • Accessories | VIDEO — DVR • TV sets and monitors • Car TV tuners • Cameras • Videomodules • Transcoders • Car TV antennas • Accessories | SECURITY SYSTEMS — Car alarms • Bike alarms • Mechanical blockers • Immobilizers • Sensors • Accessories | OPTIC AND LIGHT — Xenon • Bixenon • Lamps • LED • Stroboscopes • Optic and Headlights • Washers • Light, rain sensors • Accessories | PARKTRONICS AND MIRRORS — Rear parktronic • Front parktronic • Combined parktronic • Rear-view mirrors • Accessories | HEATING AND COOLING — Seat heaters • Mirrors heaters • Screen-wipers heaters • Engine heaters • Auto-refrigerators • Air conditioning units • Accessories | TUNING — Vibro-isolation • Noise-isolation • Tint films • Accessories | ACCESSORIES — Radar-detectors • Handsfree, Bluetooth • Windowlifters • Compressors • Bleeps, loudspeakers • Measuring instruments • Cleaners • Carsits • Miscellaneous | MOUNTING — Installation kits • Upholstery • Grilles • Tubes • Cable and wire • Tools • Miscellaneous | POWER — Batteries • Converters • Start-charging equipment • Capacitors • Accessories | MARINE AUDIO AND ELECTRONICS — Marine receivers • Marine audio speakers • Marine subwoofers • Marine amplifiers • Accessories | CAR CARE PRODUCTS — Additives • Washer fluid • Care accessories • Car polish • Flavors • Adhesives and sealants | LIQUID AND OIL — Motor oil • Transmission oil • Brake fluid • Antifreeze • Technical lubricant



In store "130" you can find and buy almost all necessary goods for your auto in Kyiv and other cities, delivery by ground and postal services. Our experienced consultants will provide you with exhaustive information and help you to chose the very particular thing. We are waiting for you at the address

<https://130.com.ua>

Pioneer

8" Tablet

English

SDA-8TAB

SDA-80TAB


Operation Manual



Table of Contents

Installing/Removing a microSD card (not included)	3
Turning the tablet on/off	3
Setting up the tablet.....	4
Additional Information.....	6

Installing/Removing a microSD card (not included)



You can install a microSD card (not included) to add additional memory space to your tablet.

Note:

The microSD card is not included. This tablet supports microSD cards with capacities up to 2 GB, and microSDHC cards with capacities up to 32 GB.

① microSD card

Turning the tablet on/off



When charged, press and hold the power button to power on the tablet.

Press and hold the power button to power off after using.


To turn the display off, press the power button shortly.

Setting up the tablet

When you first turn the tablet on, Setup Wizard guides you through the following setup process.

- Language selection
- Wi-Fi network settings (Wi-Fi connection required)
- Copy apps & data (Wi-Fi connection required)
- Google Account settings
- Date and time settings
- Google terms of service
- Screen lock settings
- Google Assistant settings

1 Turn on the tablet.



2 Select a language.

3 Tap [START].


4 Select a Wi-Fi network you want to connect to and enter the password on the next screen.

5 Tap [SKIP] if you want to skip connecting to Wi-Fi, then tap [CONTINUE] on the next screen.

Proceed to Step 8.



- 6 Transfer your data from other device(s) after connecting to a Wi-Fi network.
- 7 Sign in to your existing Google Account or create a new account after connecting to a Wi-Fi network.
- 8 Set the date and time.



- 9 Confirm the screen of Google terms of service, then tap [ACCEPT].
- 10 Set up your lock-screen security.



- 11 If you are not setting a screen lock, tap [SKIP], then [SKIP ANYWAY] on the next screen.
- 12 Set up Google Assistant.
- 13 Confirm that the home screen is displayed after setup is complete.

Home screen

Tap APP icon to configure the general settings.

Additional Information

Troubleshooting

The unit cannot be turned on

- The built-in battery is empty.
 - Charge the battery.
- The unit was left in an environment with conditions beyond its guaranteed operating range.
 - Turn on the unit when it reaches a temperature within the guaranteed operating range.

The battery cannot be charged

- The microUSB plug has not been inserted correctly into the unit's microUSB port.
 - Correctly insert the microUSB plug of the USB cable into the microUSB terminal of the main unit.
- The unit's temperature protection function was activated because of the increase in the unit's temperature caused by the usage conditions.
 - Charge the battery after the unit cools down.
- The unit's temperature protection function was activated because of the decrease in the unit's temperature caused by a low-temperature environment.
 - Charge the battery after the unit warms up.

Even when fully charged, the battery life is exceptionally short

- The built-in battery has a short battery life.
 - Contact your dealer or an authorized Pioneer Service Station for assistance.

There is no sound, or the sound volume is low

- Audio volume is set to 0, or the audio volume is set very low.
 - Turn up the audio volume.

There are tiny black or bright spots showing up on the screen

- This is a phenomenon unique to liquid crystal displays and is not a malfunction.
 - N/A.

Copyright and trademark

Google™ and Android™

Google and Android are trademarks of Google LLC.

microSD, microSDHC



microSD, microSDHC Logos are trademarks of SD-3C LLC.

Specifications

Operating System

Android 9 Pie

CPU

ARM Quad core Cortex-A7 1.8 GHz

RAM

2 GB

ROM

16 GB

Display

Screen size 8 inch

Screen resolution WXGA (800 × 1280) IPS

Touch Panel

5 Points capacitive touch panel Glass + Glass

Camera

Front side 0.3 M pixel Fixed Focus

Rear side 2.0 M pixel Fixed Focus

GNSS

Positioning method (GPS / Glonass)

Sensor

Acceleration sensor: 3 Axis

Illuminance sensor

Speaker

Built-in speaker 1.0 W/8 Ω (Mono)

Microphone

Built-in microphone (Mono)

Network Connections**Wi-Fi**

IEEE802.11b/g/n (2.4 GHz)

Bluetooth

Ver: Bluetooth 4.2 (Class 2)

Profiles SPP/A2DP/AVRCP

Interface Configuration**Headphone jack (1-input)**

φ 3.5 mm standard headphone jack CTIA

USB Interface

microUSB type-B × 1 (USB-OTG)

Memory Card Slot

microSD card × 1

Supported SD Memory Card: microSD, microSDHC

SD Speed Class: Class 10

Playable video format

MPEG4-SP, H.264/AVC, H.263, AVI,

H-265/HEVC, -VP9, MPEG2, FLV

Playable image format (Google_CDD required)

JPEG, GIF, PNG, BMP, WebP, Raw, HEIF

Playable audio format (Google_CDD required)

AAC_LC, AAC+, enhanced_AAC+, AAC ELD,

xHE-AAC (USAC/AMR-NB/AMR-WB), FLAC, MP3, PCM/WAVE

Dimensions

213 × 125 × 11.4 mm

217 × 141 × 15 mm (with tablet case)

Weight

393 g

490 g (with tablet case)

Built-in Battery

Capacity: About 4000 mAh

Power supply

USB or Built-in Battery

Operating temperature

-10°C~60°C (When operating)

Accessories

USB cable (microUSB_B - USB_A), Tablet Case, Owner's manual,

Warranty card, Caution card

Bluetooth

Output power: +4 dBm Maximum (Power class 2)

Frequency band(s): 2 400 MHz to 2 483.5 MHz

<https://www.pioneer-car.eu/eur/>

Visit **www.pioneer-car.eu/uk/** (or **www.pioneer-car.eu/eur/**) to register your product.

Visitez **www.pioneer-car.eu/fr/fr/** (ou **www.pioneer-car.eu/eur/**) pour enregistrer votre appareil.

Si prega di visitare il sito **www.pioneer-car.eu/it/it/** (o **www.pioneer-car.eu/eur/**) per registrare il prodotto.

Visite **www.pioneer-car.eu/es/es/** (o **www.pioneer-car.eu/eur/**) para registrar su producto.

Zum Registrieren Ihres Produktes besuchen Sie bitte **www.pioneer-car.eu/de/de/** (oder **www.pioneer-car.eu/eur/**).

Bezoek **www.pioneer-car.eu/nl/nl/** (of **www.pioneer-car.eu/eur/**) om uw product te registreren.

Посетите **www.pioneer-rus.ru/** (или **www.pioneer-car.eu/eur/**) для регистрации приобретенного Вами изделия.

PIONEER CORPORATION

28-8, Honkomagome 2-chome, Bunkyo-ku,
Tokyo 113-0021, Japan

Корпорация Пайонир

28-8, Хонкомагомэ 2-чоме, Бункё-ку,
Токио 113-0021, Япония

Импортер ООО "ПИОНЕР РУС"

105064, Россия, г. Москва, Нижний Сусальный переулок,
дом 5, строение 19
Тел.: +7(495) 956-89-01

PIONEER EUROPE NV

Haven 1087, Keetberglaan 1, B-9120 Melsele, Belgium/Belgique
TEL: (0) 3/570.05.11

PIONEER ELECTRONICS (USA) INC.

P.O. Box 1540, Long Beach, California 90801-1540, U.S.A.
TEL: (800) 421-1404

PIONEER ELECTRONICS ASIACENTRE PTE. LTD.

2 Jalan Kilang Barat, #07-01, Singapore 159346
TEL: 65-6378-7888

PIONEER ELECTRONICS AUSTRALIA PTY. LTD.

5 Arco Lane, Heatherston, Victoria, 3202 Australia
TEL: (03) 9586-6300

PIONEER ELECTRONICS DE MÉXICO S.A. DE C.V.

Bldv. Manuel Ávila Camacho 138, 10 piso
Col.Lomas de Chapultepec, México, D.F. 11000
Tel: 52-55-9178-4270, Fax: 52-55-5202-3714

先鋒股份有限公司

台北市內湖區瑞光路407號8樓
電話：886-(0) 2-2657-3588

先鋒電子(香港)有限公司

香港九龍長沙灣道909號5樓
電話：852-2848-6488

© 2019 PIONEER CORPORATION. All rights reserved.

<OPM_SDA8TABEU5_EG_B> EU5/UR

Autogoods "130"