



PHONES

0 (800) 800 130  
(050) 462 0 130  
(063) 462 0 130  
(067) 462 0 130

**130**  
COM.UA

Internet store of  
autogoods



SKYPE

km-130

CAR RECEIVERS — Receivers • Media receivers and stations • Native receivers • CD/DVD changers • FM-modulators/USB adapters • Flash memory • Facia plates and adapters • Antennas • Accessories |  
CAR AUDIO — Car audio speakers • Amplifiers • Subwoofers • Processors • Crossovers • Headphones • Accessories | TRIP COMPUTERS — Universal computers • Model computers • Accessories |  
GPS NAVIGATORS — Portable GPS • Built-in GPS • GPS modules • GPS trackers • Antennas for GPS navigators • Accessories | VIDEO — DVR • TV sets and monitors • Car TV tuners • Cameras • Videomodules  
• Transcoders • Car TV antennas • Accessories | SECURITY SYSTEMS — Car alarms • Bike alarms • Mechanical blockers • Immobilizers • Sensors • Accessories | OPTIC AND LIGHT — Xenon • Bixenon • Lamps  
• LED • Stroboscopes • Optic and Headlights • Washers • Light, rain sensors • Accessories | PARKTRONICS AND MIRRORS — Rear parktronic • Front parktronic • Combined parktronic • Rear-view mirrors  
• Accessories | HEATING AND COOLING — Seat heaters • Mirrors heaters • Screen-wipers heaters • Engine heaters • Auto-refrigerators • Air conditioning units • Accessories | TUNING — Vibro-isolation  
• Noise-isolation • Tint films • Accessories | ACCESSORIES — Radar-detectors • Handsfree, Bluetooth • Windowlifters • Compressors • Beeps, loudspeakers • Measuring instruments • Cleaners • Car seats  
• Miscellaneous | MOUNTING — Installation kits • Upholstery • Grilles • Tubes • Cable and wire • Tools • Miscellaneous | POWER — Batteries • Converters • Start-charging equipment • Capacitors  
• Accessories | MARINE AUDIO AND ELECTRONICS — Marine receivers • Marine audio speakers • Marine subwoofers • Marine amplifiers • Accessories | CAR CARE PRODUCTS — Additives • Washer fluid •  
Care accessories • Car polish • Flavors • Adhesives and sealants | LIQUID AND OIL — Motor oil • Transmission oil • Brake fluid • Antifreeze • Technical lubricant



In store "130" you can find and buy almost all necessary goods for your auto in Kyiv and other cities, delivery by ground and postal services. Our experienced consultants will provide you with exhaustive information and help you to choose the very particular thing. We are waiting for you at the address

<https://130.com.ua>

**RAC750 Operating Instructions**  
**230v Mains Powered Rapid Air Compressor**

**Caution**

Before operating this compressor, please read the instruction leaflet and retain for future reference. Operate only in accordance with the instructions

When using the compressor ensure you are parked in a safe location, off the road with the handbrake fully engaged. Ensure your personal safety is not at risk. The Compressor must not be used when the vehicle is moving. Never leave the compressor unattended.

- Power supply required 230v AC
- This compressor is designed for occasional use. Operation over an extended period may overheat the unit and damage the compressor. It should not be used continuously for more than 15 minutes. After 15 minutes, turn it off and let it cool for 15 minutes before resuming.
- If the compressor is making an abnormal sound, or the temperature of the unit is too high, turn the power off immediately and let it cool for at least 15 minutes before resuming operation.
- Do not use the air compressor on high pressure tyres such as those used on commercial vehicles, agricultural or specialist vehicles.
- When the air compressor is in use do not direct the air pressure towards a person.
- Store in a dry place.
- Do not position close to inflammable liquids or gas.
- Operate only in dry conditions.
- Only use the adapters supplied with the device.
- The gauge on this compressor is for guidance only. Check pressure with a known accurate gauge.
- Inspect before each use. Do not use the compressor if any of the components are damaged.
- Do not kink or block the air hose while the compressor is working.

**To Inflate Vehicle Tyres**

- Insert the fused plug into the 230v mains socket
- After removing the dust caps connect the air hose to the tyre valve stem and push down with your thumb the locking lever connector. Ensure the connector is securely connected (See Fig 1, 2 )
- Push the ON / OFF button to switch the compressor on.
- When the desired pressure is reached push the ON / OFF button to switch off.
- Release the locking lever and remove the air line from the tyre valve and replace the dust caps, remove the 230v plug from the mains socket.

**Fig 1**



**Fig 2**



### **For Leisure Accessorises**

- Select the appropriate adapter and insert into the valve stem push down with your thumb the locking lever connector.
- Insert the connector adapter into the appropriate inlet of the inflatable.
- Insert the plug securely into a 230v mains socket.
- Push the ON / OFF button to switch the compressor on.
- Only inflate product to the manufacturer's specifications.



### **Typical Inflation Pressure**

Bicycle tyres 35-40psi  
Basketball 9psi

Car Tyre 30-40psi  
Volleyball 5psi

Lawn tractor tyre 22psi  
Football 13psi

- Caution should be taken not to over inflate.
- Push the ON/ OFF button to switch the compressor off.
- Remove adapter from the inflatable and turn off the AC supply.
- Remove the 230v plug from the mains socket

### **To Replace the Fuse**

- Using the appropriate size screwdriver remove the screws from the plug remove the old fuse and replace only with a 3 amp rated fuse.
- Replace the plug lid and tighten the screws in the plug.

Distributed by Ring Automotive Ltd, Gelderd Road, Leeds, England, LS12 6NA.  
Tel: +44 (0)113 2132000, Fax: +44 (0)113 2310266

**E-mail: [autosales@ringautomotive.co.uk](mailto:autosales@ringautomotive.co.uk) Web: [www.ringautomotive.co.uk](http://www.ringautomotive.co.uk)**

Ring Automotive Ref:- L294