



PHONES

0 (800) 800 130
 (050) 462 0 130
 (063) 462 0 130
 (067) 462 0 130



SKYPE

km-130

130

COM.UA

Internet store of autogoods

CAR RECEIVERS — Receivers • Media receivers and stations • Native receivers • CD/DVD changers • FM-modulators/USB adapters • Flash memory • Facia plates and adapters • Antennas • Accessories |
 CAR AUDIO — Car audio speakers • Amplifiers • Subwoofers • Processors • Crossovers • Headphones • Accessories | TRIP COMPUTERS — Universal computers • Model computers • Accessories |
 GPS NAVIGATORS — Portable GPS • Built-in GPS • GPS modules • GPS trackers • Antennas for GPS navigators • Accessories | VIDEO — DVR • TV sets and monitors • Car TV tuners • Cameras • Videomodules
 • Transcoders • Car TV antennas • Accessories | SECURITY SYSTEMS — Car alarms • Bike alarms • Mechanical blockers • Immobilizers • Sensors • Accessories | OPTIC AND LIGHT — Xenon • Bixenon • Lamps
 • LED • Stroboscopes • Optic and Headlights • Washers • Light, rain sensors • Accessories | PARKTRONICS AND MIRRORS — Rear parktronics • Front parktronics • Combined parktronics • Rear-view mirrors
 • Accessories | HEATING AND COOLING — Seat heaters • Mirrors heaters • Screen-wipers heaters • Engine heaters • Auto-refrigerators • Air conditioning units • Accessories | TUNING — Vibro-isolation
 • Noise-isolation • Tint films • Accessories | ACCESSORIES — Radar-detectors • Handsfree, Bluetooth • Windowlifters • Compressors • Beeps, loudspeakers • Measuring instruments • Cleaners • Carsits
 • Miscellaneous | MOUNTING — Installation kits • Upholstery • Grilles • Tubes • Cable and wire • Tools • Miscellaneous | POWER — Batteries • Converters • Start-charging equipment • Capacitors
 • Accessories | MARINE AUDIO AND ELECTRONICS — Marine receivers • Marine audio speakers • Marine subwoofers • Marine amplifiers • Accessories | CAR CARE PRODUCTS — Additives • Washer fluid •
 Care accessories • Car polish • Flavors • Adhesives and sealants | LIQUID AND OIL — Motor oil • Transmission oil • Brake fluid • Antifreeze • Technical lubricant



In store "130" you can find and buy almost all necessary goods for your auto in Kyiv and other cities, delivery by ground and postal services. Our experienced consultants will provide you with exhaustive information and help you to chose the very particular thing. We are waiting for you at the address

<https://130.com.ua>

GROUND ZERO®
GERMAN ENGINEERING

PLUTONIUM SERIES
Amplifier

**GZPA 2SQ
GZPA 4SQ**

**Owner's Manual
& Installation Guide**

English

130.com.ua

Introduction

Thank you for choosing a GROUND ZERO product and welcome to your new PLUTONIUM series amplifier!

This is the owner's manual providing instructions on the operation and installation of this high-end car amplifier. Please, read it carefully. If you have any further questions, please contact your local Ground Zero dealer or our regional distribution partner.

The amplifier is one of the most important parts of your car audio system. However, it will only be able to deliver its full performance when each part of the whole system is tuned carefully matching each other. Therefore, we recommend consulting a car audio specialist to compile the desired sound system, as well as for installation and tuning.

We hope you will enjoy the sound quality of an enthusiastic development by the Ground Zero engineering team!

PLUTONIUM Series – The High-End Experience

Products belonging to the GROUND ZERO PLUTONIUM series stand for high-end sound quality or extreme power handling capability.

To achieve one of these targets, exceptional materials and technologies are applied during the development.

The technical, electrical and mechanical skills of the resulting products convince not only during worldwide sound quality competitions but also satisfy the demands of high-end enthusiasts with outstanding audio reproduction ability.

Starting from the market release, the subwoofers have set benchmarks in SPL competitions around the world and have been awarded for best performance by numerous test magazines.

The GZPA SQ amplifiers have been developed by experienced sound quality engineers and tuned by music loving enthusiasts. They are being built with highest care using some of the best quality parts available and run through numerous tests prior to handing over to GROUND ZERO partners and retail shops.

Terms of Warranty

The limited warranty for this product is covered by GROUND ZERO's regional distribution partners and their terms and conditions. For further information contact your local retailer or regional distributor.

GROUND ZERO®

GERMAN ENGINEERING

PLUTONIUM SERIES

Amplifiers

GZPA 2 SQ

GZPA 4 SQ


Features

- High-End SQ amplifier
- Shielded dual power supply
- Discretely constructed MOS-FET amplifier section
- 1-ohm stable stereo / 2-ohms stable in bridged mode
- Smoothly variable BIAS adjustment
- Variable input sensitivity
- Capsulated potentiometers
- Wide range high pass and low pass filter
- Filter range multiplication switch (x10)
- Wide frequency range for high resolution music (10 Hz – 50 kHz)
- Soft start delay
- Operation and protection indicator
- Start-Stop capability (9 -16 Volt)
- Overheat and short circuit protection
- Low distortion Burr-Brown OPA2134PA operation amplifier
- Ground Zero exclusive Mundorf Mcap® capacitors
- Solid and high efficient black anodized heatsink
- White illuminated lasered glass logo plate
- Phase control (GZPA 2SQ)
- Pure Direct mode (GZPA 2SQ)

General installation note

- As a precaution, it is recommended to disconnect the vehicles battery before mounting the amplifier.
(Note: For new vehicles, disconnecting the battery might cause various errors in your vehicle's electric system that can be cleared only by authorized service partners of your vehicle's manufacturer! Please ask your service partner first before disconnecting the battery!)
- The power supply wire (+12 V) has to be protected within max. 20 cm / 8" by a main fuse holder with a fuse value matching the recommendation for your amplifier
(Note: If there is more than one amplifier connected using this power wire, the main fuse value must be equal to the sum of the recommended fuses of all connected devices. However, make sure the diameter of your power wire will be sufficient for the required current!)
- If necessary, replace a defective fuse by a fuse with identical quality and value
- Never drill a hole to the vehicles gas tank or brake lines, to wirings or any other important vehicle parts!
- Never pass wires over sharp edges or vehicle parts due avoid any kind of damage
- Keep the wiring away from the antenna and electronic devices contributing to radio reception
- Lay the power supply wiring always separated from speaker wiring to avoid disturbance
- The amplifier contains a temperature protection circuit that turns the device off in case of overheating. After a certain cooling time, it will turn on automatically. To avoid heat build-up, sufficient air supply for cooling must be provided. Never cover the surface of the amplifier's heatsink entirely
- The amplifier should **NEVER** be mounted onto a vibrating part or surface such as a subwoofer enclosure. This might lead to malfunction due to loose electrical parts inside the amplifier.
- Some amplifiers offer a high-level input option, however if a pre-amplified output (RCA) is available (at the head unit), it is strongly recommended to make use of them.

Controls and functions GZPA 2SQ



1	Power terminal	GROUND REMOTE BATT+	Vehicle ground connection Remote connection (turn-on voltage) 12 Volt (Battery)
2	Speaker terminal		Speaker wire connection
3	Signal input		RCA wire connection
4	Input sensitivity		Control for correct input sensitivity adjustment
5	High pass switch		Switch to activate the high pass filter
6	High pass multiplier		Switch to multiply (x10) the high pass filter frequency range
7	High pass frequency		Control to adjust the correct high pass filter frequency
8	Low pass switch		Switch to activate the low pass filter
9	Low pass multiplier		Switch to multiply (x10) the low pass filter frequency range
10	Low pass frequency		Control to adjust the correct low pass filter frequency
11	Bypass function		Switch to deactivate both crossover filters (Direct signal path)
12	Phase switch		Switch to activate the phase adjustment control
13	Phase adjustment		Control to adjust the correct phase
14	BIAS adjustment		Control to adjust the BIAS setting (check the BIAS adjustment info below)
15	Status indication	POWER PROTECT	(white) indicates the correct operation mode (red) indicates a defect / activated protection mode


BIAS adjustment

Adjusting the BIAS setting influences the operation mode and sound of the amplifier. Increasing the BIAS setting clockwise leads to a warm sound experience with wide stereoscopic sound comparable to the performance of a Class A amplifier with increased current consumption und heat generation. Reducing the BIAS setting counterclockwise results in direct and clear music reproduction. Depending on the speaker's characteristics and the mounting positions, the adjustment is up to the listener's taste of music reproduction. The BIAS setting however, does not influence the general output power of the amplifier.


LED illumination

Optionally, the LED illumination of the Ground Zero logo can be switched off. For this purpose, the jumper positioned on the back side of the top aluminum cover needs to be removed from the illumination pc board.


Connections GZPA 2SQ – stereo mode



Connections GZPA 2SQ – bridged mode



Controls and functions GZPA 4SQ



1	Power terminal	GROUND Vehicle ground connection REMOTE Remote connection (turn-on voltage) BATT+ 12 Volt (Battery)
2	Speaker terminals	Speaker wire connections
3	Signal input	RCA wire connection
4	Input sensitivity	Control for correct input sensitivity adjustment
5	High pass switches	Switches to activate the high pass filter (separately for front and rear)
6	High pass multipliers	Switches to multiply (x10) the high pass filter frequency range
7	High pass frequency	Controls to adjust the correct high pass filter frequency
8	Low pass switch	Switches to activate the low pass filter (separately for front and rear)
9	Low pass multiplier	Switches to multiply (x10) the low pass filter frequency range
10	Low pass frequency	Controls to adjust the correct low pass filter frequency
14	BIAS adjustment	Controls to adjust the BIAS setting (check the BIAS adjustment info below) for each pair of channels separately
15	Status indication	POWER (white) indicates the correct operation mode PROTECT (red) indicates a defect / activated protection mode


BIAS adjustment

Adjusting the BIAS setting influences the operation mode and sound of the amplifier. Increasing the BIAS setting clockwise leads to a warm sound experience with wide stereoscopic sound comparable to the performance of a Class A amplifier with increased current consumption und heat generation. Reducing the BIAS setting counterclockwise results in direct and clear music reproduction. Depending on the speaker's characteristics and the mounting positions, the adjustment is up to the listener's taste of music reproduction. The BIAS setting however, does not influence the general output power of the amplifier.


LED illumination

Optionally, the LED illumination of the Ground Zero logo can be switched off. For this purpose, the jumper positioned on the back side of the top aluminum cover needs to be removed from the illumination pc board.

Connections GZPA 4SQ – stereo mode



Connections GZPA 4SQ – bridged mode



Trouble shooting

The amplifier includes protection features to prevent any kind of damage caused by misuse or faulty conditions. Sensor-detected short circuit at the speaker terminals or an impedance below the permitted value lights up the protection indicators and turns off the amplifier.

To determine the problem, the volume should be reduced to minimum, the power supply disconnected, and the installation checked carefully for wiring mistakes or defects.

If the amplifier shuts down due to excessive heat, the protection indicators will not light up. In this case the amplifier just needs a certain time to cool down.

Check the following table to solve a problem. It's recommended to check the speakers and speaker wires first, whenever the protection mode has been activated (PROTECT).

Problem	Check point	Reason / action
No audible signal	POWER indication status	Check the fuse(s) Check the power connection Check the ground connection Check the remote wire connection
	PROTECT indication status	Speaker short circuit → Check the speakers and speaker wires Amplifier overheated → Wait for cooling down Probably damaged amplifier → Contact a Ground Zero service partner
Amplifier is not switching to operation mode	Power supply	Check the fuse(s) Check the power connection Check the ground connection
	Remote (turn-on) voltage	Check the remote (out) voltage at the head unit
Amplifier switches off or into protection mode at high levels	Speaker impedance Speaker wiring	Check if the impedance at the speaker wire dropped below the permitted value
No audible signal at one of the amplifiers channels	RCA cable / speaker wires	Check the terminals and RCA connectors (check the audio signal on each RCA cable)

Specifications

Model	GZPA 2SQ	GZPA 4SQ
RMS Power @ 4 Ω (14.6 V)	2 x 175 W (1% THD+N)	4 x 125 W (1% THD+N)
RMS Power @ 2 Ω (14.6 V)	2 x 315 W (1% THD+N)	4 x 225 W (1% THD+N)
RMS Power @ 1 Ω (14.6 V)	2 x 500 W (1% THD+N)	4 x 350 W (1% THD+N)
RMS Power @ 4 Ω bridged (14.6 V)	1 x 630 W (1% THD+N)	2 x 450 W (1% THD+N)
RMS Power @ 2 Ω bridged (14.6 V)	1 x 1000 W (1% THD+N)	2 x 700 W (1% THD+N)
Damping factor (20 Hz)		> 220
High pass filter (pair of channels)		20 – 400 Hz / 200 – 4000 Hz (switchable)
Low pass filter (pair of channels)		20 – 400 Hz / 200 – 4000 Hz (switchable)
Phase control	Yes	No
Pure direct mode	Yes	No
BIAS control	Yes	Yes
Distortion		<0.01% (4 ohms load)
Signal to noise ratio (SNR)		> 90 dB
Frequency response		10 Hz – 50 kHz (± 1 dB)
Input sensitivity range		1 V – 6 V
Fuse(s)		3 x 40 A (internal/under the bottom plate)
Recommended main fuse		1x 120 A
Operating voltage range		9 – 16 Volt
Dimensions W x H x L mm		222 x 60.5 x 420
Dimensions W x H x L inch		8.74" x 2.38" x 16.54"
Weight	6.0 kg	6.2 kg


Ground Zero GmbH

Erlenweg 25, 85658 Egmating, Germany

Tel. +49 (0)8095/873-830

www.ground-zero-audio.com





www.ground-zero-audio.com

Tel. +49 (0)8095/873-830

Erlenweg 25, 85658 Egmatting, Germany

Ground Zero GmbH

Modell	GZPA 2S@	GZPA 4S@	RMS Leistung @ 4 Q (14.6 V)	RMS Leistung @ 2 Q (14.6 V)	RMS Leistung @ 1 Q (14.6 V)	RMS Leistung @ 4 Q bridged (14.6 V)	RMS Leistung @ 2 Q bridged (14.6 V)	Däppungsfaktor (20 Hz)	Hochpassfilter (paraweise)	Tiefpassfilter (paraweise)	Phasenkorrektur	Pure direct mode	Verzerrungen	Signalauschabstand (SNR)	Frequenzgang	Eingangssempfindlichkeit	Sicherung(en)	Empfohlene Hauptsicherung	Ableiterreich	Masse	Gewicht				
			2 x 175 W (1% THD+N)	2 x 315 W (1% THD+N)	2 x 500 W (1% THD+N)	1 x 630 W (1% THD+N)	1 x 1000 W (1% THD+N)	> 220	20 - 400 Hz / 200 - 4000 Hz (umschaltbar)	20 - 400 Hz / 200 - 4000 Hz (umschaltbar)	Ja	Ja	< 0.01% (4 Ohm Last)	> 90 dB	10 Hz - 50 KHz (± 1 dB)	1 V - 6 V	3 x 40 A (intern/unter der Bodenverkleidung)	1x 120 A	9 - 16 Volt	222 x 60.5 x 420 mm	Maße	B x H x L mm	6.0 kg	6.2 kg	Gewicht
			4 x 125 W (1% THD+N)	4 x 225 W (1% THD+N)	4 x 350 W (1% THD+N)	2 x 450 W (1% THD+N)	2 x 700 W (1% THD+N)	< 220	20 - 400 Hz / 200 - 4000 Hz (umschaltbar)	20 - 400 Hz / 200 - 4000 Hz (umschaltbar)	Ja	Ja	< 0.01% (4 Ohm Last)	> 90 dB	10 Hz - 50 KHz (± 1 dB)	1 V - 6 V	3 x 40 A (intern/unter der Bodenverkleidung)	1x 120 A	9 - 16 Volt	222 x 60.5 x 420 mm	Maße	B x H x L mm	6.0 kg	6.2 kg	Gewicht
			4 x 125 W (1% THD+N)	4 x 225 W (1% THD+N)	4 x 350 W (1% THD+N)	2 x 450 W (1% THD+N)	2 x 700 W (1% THD+N)	< 220	20 - 400 Hz / 200 - 4000 Hz (umschaltbar)	20 - 400 Hz / 200 - 4000 Hz (umschaltbar)	Ja	Ja	< 0.01% (4 Ohm Last)	> 90 dB	10 Hz - 50 KHz (± 1 dB)	1 V - 6 V	3 x 40 A (intern/unter der Bodenverkleidung)	1x 120 A	9 - 16 Volt	222 x 60.5 x 420 mm	Maße	B x H x L mm	6.0 kg	6.2 kg	Gewicht
			4 x 125 W (1% THD+N)	4 x 225 W (1% THD+N)	4 x 350 W (1% THD+N)	2 x 450 W (1% THD+N)	2 x 700 W (1% THD+N)	< 220	20 - 400 Hz / 200 - 4000 Hz (umschaltbar)	20 - 400 Hz / 200 - 4000 Hz (umschaltbar)	Ja	Ja	< 0.01% (4 Ohm Last)	> 90 dB	10 Hz - 50 KHz (± 1 dB)	1 V - 6 V	3 x 40 A (intern/unter der Bodenverkleidung)	1x 120 A	9 - 16 Volt	222 x 60.5 x 420 mm	Maße	B x H x L mm	6.0 kg	6.2 kg	Gewicht

Technische Daten

Problem	Kontrolle	Grund / Abhilfe	Keine Tonausgabe	PROTECT Anzeige	Gerät überhitzt	→ Lautsprach Fehler und Kabel prüfen	Gerät abkühlen lassen	Evenuell er Schaden am Gerät	12 Volt Versorgung prüfen	Massenschluss am Lautsprecher	Kurzschluss am Lautsprecher	Stromzuführ	nicht ein	Versäkter schafft sich bei aktiver die Schutzschaltung wurde höherer Lautstärke ab oder lautsprachereinschaltung den minimal zulässigen Wert unterschreitet	Lautspracherkabel	Cinch- und/oder Cinchkabel und -stecker sowie die Lautsprachereinschaltung und -leitungen prüfen (Prüfen, ob auf allen Cinchleitungen ein Signal anliegt)	Kein Ton an einem der Versäkernähle


Folgende Tabelle gibt weitere Hinweise zur Fehlerbehebung. Für den Fall, dass die Schutzschaltung (PROTECT) aktiviert wurde, empfiehlt es sich generell zuerst die Lautsprach Fehler und die Verkabelung zu überprüfen.

Bei Überhitzung des Kühlükpers leuchtet die Statusanzeige nicht rot auf. In diesem Fall benötigt das Gerät lediglich etwas Zeit um soweit abzukühlen, dass die Temperatur wieder im zulässigen Bereich liegt.


Um das Problem feststellen und zu beheben, sollte der Lautstärkeregler auf das Minimum reduziert, die Stromversorgung getrennt und die Installation sorgfältig auf Kurzschluss oder falsche Anschlüsse geprüft werden.

Der Versäkter befindet Funktionen, welche Schaden durch unsachgemäße Bedienung oder fehlerhaften Anschluss vermeiden sollen. Sobald die Sensoren einen Kurzschluss oder eine Meldung feststellen, welche unter dem zulässigen Wert liegt, leuchtet die Statusanzeige (PROTECT) rot und das System schaltet sich ab bis der Fehler behoben wurde.

Fehleruche



Anschluss GZPA 45Q – Brückenebetrieb



Anschluss GZPA 45Q – Stereobetrieb


Die LED Belieuchtung des Ground Zero Logos kann auf Wunsch deaktiviert werden. Hierzu befindet sich auf der Unterseite der Aluminium-Abdeckung eine Steckbrücke, welche bei Bedarf entfernt werden kann.

LED Belieuchtung


Die BLAS Einstellung beeinflusst den Klang des Verstärkers. Das Erhöhen der BLAS-Einstellung führt zu einem warmen Klangbild mit weiter Raumabstimmung, vergleichbar mit dem eines Class A Verstärker, aber erhöht auch die Stromaufnahme und Wärmeentwicklung. Durch das Verringern der BLAS-Einstellung klingt der Verstärker eher direkt und klar. Unter Berücksichtigung der Lautsprecher und deren Einbaupositionen lässt sich somit der gewünschte Klang-Charakter festlegen. Die Ausgangseinstellung bleibt durch die BLAS-Einstellung jedoch unverändert.

BLAS Einstellung


15	Betriebsanzeige	PROTECT (rot) signalisiert einen Fehler / aktive Schutzschaltung
14	BLAS Einstellung	Regler zur BLAS-Einstellung (siehe auch Info zur BLAS-Einstellung unten)
10	Tiefpass Frequenz	Regler zur Einstellung der Tiefpass-Frequenz
9	Tiefpass Multiplikator	Schalter zur Aktivierung des (x10) Multiplikators für die Tiefpass-Frequenzweiche
8	Tiefpass Schalter	Schalter zur Aktivierung der Tiefpass-Frequenzweiche
7	Hochpass Frequenzen	Regler zur Einstellung der Hochpass-Frequenz
6	Hochpass Multiplikator	Schalter zur Aktivierung des (x10) Multiplikators für die Hochpass-Frequenzweiche
5	Hochpass Schalter	Schalter zur Aktivierung der Hochpass-Frequenzweiche
4	Eingangsempfindlichkeit	Regler zur Einstellung der Korrektur Eingangsempfindlichkeit
3	Signaleingang	Anschluss für die Cinchkabel
2	Lautsprecheranschluss	Anschluss für die Lautsprecherkabel
1	Stromanschluss	GROUND Massen Anschluss REMOTE Remote Anschluss (Einschaltspannung)



Einstellungen und Funktionen GZPA 4SQ



Anschlisse GZPA 250 – Brückeneinbetrieb



Anschlisse GZPA 250 – Stereoanbetrieb


Die LED Beleuchtung des Ground Zero Logos kann auf Wunsch deaktiviert werden. Hierzu befindet sich auf der Unterseite der Aluminium-Abdeckung eine Schiebbrücke, welche bei Bedarf entfernt werden kann.

LED Beleuchtung

Die BLAS Einstellung beeinflusst den Klang des Verstärkers. Das Erhöhen der BLAS Einstellung führt zu einem warmen Klangerbil mit weiter Raumabbildung, vergleichbar mit dem elnies Class A Verstärker, aber erhöht auch die Stromaufnahme und Wärmeentwicklung. Durch das Verringern der BLAS Einstellung klingt der Verstärker eher direkt und klar. Unter Berücksichtigung der Lautsprecher und deren Einbaupositionen lässt sich somit der gewünschte Klang-Charakter festlegen. Die Ausgangsleistung bleibt durch die BLAS Einstellung jedoch unverändert.

BLAS Einstellung

15	Betriebsanzeige	PROTECT (rot) signalisiert einen Fehler / aktive Schutzaufung
14	BLAS Einstellung	Regler zur BLAS Einstellung (siehe auch Info zur BLAS Einstellung unten)
13	Phaseneinstellung	Regler zur Einstellung der Phaseneinstellung
12	Phasenschalter	Schalter zur Aktivierung der Phaseneinstellung
11	Tiefpass Funktion	Schalter zur Deaktivierung beider Frequenzweichen (Direkter Signalausgang)
10	Tiefpass Frequenz	Regler zur Einstellung der Tiefpass Frequenz
9	Tiefpass Multiplikator	Schalter zur Aktivierung des (x10) Multiplikators für die Tiefpass-Frequenzweiche
8	Tiefpass Schalter	Schalter zur Aktivierung der Tiefpass-Frequenzweiche
7	Hochpass Frequenz	Regler zur Einstellung der Hochpass Frequenz
6	Hochpass Multiplikator	Schalter zur Aktivierung des (x10) Multiplikators für die Hochpass-Frequenzweiche
5	Hochpass Schalter	Schalter zur Aktivierung der Hochpass-Frequenzweiche
4	Eingangsempfindlichkeit	Regler zur Einstellung der Korrektur Eingangsempfindlichkeit
3	Signaleingang	Anschluss für die Cinchkabel
2	Lautsprecheranschluss	Anschluss für die Lautsprecherkabel
1	Stromanschluss	GRUNDE Masse Anschluss (Einschaltspannung)
		REMOTE Remote Anschluss (Batterie)
		BATT+ 12 Volt (Batterie)




Einstellungen und Funktionen GZPA 25Q

- Als Vorsichtsmabnahme wird empfohlen, die Fahrzeugbatterie vor der Installation zu trennen!
- Hinweis: Bei einigen neueren Fahrzeugen kann das Trennen der Batterie zu Fehlermeldungen der Bordlektrik führen, welche ausschließlich durch eine autorisierte Fachwerkstatt gelöst werden
- Hinweis: Bei einigen neueren Fahrzeugen kann das Trennen der Batterie zu Fehlermeldungen der Servicepartner für Ihr Fahrzeug, bevor Sie die Batterie trennen!)
- Das Hauptstromkabel muss innerhalb der ersten 20 cm nach dem Anschluss an der Batterie durch eine geeignete Sicherung mit dem in der Anleitung genannten Wert abgesichert werden.
- Hinweis: Wenn das Hauptstromkabel mehrere Verbraucher versorgt, sollte der Wert der Summe aller empfohlenen Sicherungsweite entsprechen. Hierbei muss gewährleistet sein, dass der gewählte Kabelquerschnitt für eine entsprechende Stromstärke geeignet ist.)
- Wenn notwendig, sollten defekte Sicherungen ausschließlich durch neue Sicherungen ersetzt werden Qualität und mit identischem Sicherungswert ersetzt werden
- Niemals Löcher in den Tank, die Bremsleitung, Kabel oder andere wichtige Fahrzeugteile bohren!
- Kabel niemals über schärfte Kanten führen, die zu Beschädigungen führen können
- Signal- und Lautsprecherkabel weitesgehend getrennt von Stromführern Kabeln verlegen verlegen, die für den Radiomprang wichtig sind
- Der Verstärker verfügt über eine thermische Schutzsicherung, welche bei zu hoher Temperatur das Gerät abschaltet; nach der Abschaltung schaltet sich dieses wieder selbstständig ein. Um einen Warmlauf zu vermeiden, sollte für ausreichende Lufzufuhr zur Kühlung gesorgt werden. Die Obersilber des Kuhlkörpers darf nicht vollständig abgedeckt werden
- Der Verstärker verfügt über eine thermische Schutzsicherung, welche bei zu hoher Temperatur das Gerät abschaltet; nach der Abschaltung schaltet sich dieses wieder selbstständig ein. Um einen Warmlauf zu vermeiden, sollte für ausreichende Lufzufuhr zur Kühlung gesorgt werden. Die Obersilber des Kuhlkörpers darf nicht vollständig abgedeckt werden
- Der Verstärker sollte **NIELS** auf stark vibrierenden Bauteilen oder Oberflächen montiert werden wie z.B. Subwoofer-Gehäusen. Dies könnte zu Fehlfunktionen aufgrund sich gelöster Bauteile führen

- High-End SQ Verstärker
- Diskret aufgebau te MOS-FET Endstufensteckle
- Geeschirmte Dual-Hochleistungsnetzteilie
- Stufenlos regelbare BLAS Einstellung
- Regelbare Eingangsempfindlichkeit
- Gekapselte Potenzimeter
- Hochpass- und Tiefpass-Filte mit weitem Regelbereich
- Frequenzweichen-Multifilte (x10)
- Breiter Frequenzgang für hochfrequente Wiedergabe (10 Hz – 50 kHz)
- Einschalt- und Schutzzanzüge
- Start-Stop Stabilität (9 -16 Volt)
- Ubehitzung-, Überspannungs- und Kurzschluss-Schutzschaltung
- Verzerrungssarme Burr-Brown OP2134PA Operatorenverstärker
- Gro und Zero exklusive Mundorf Mcap® Kondensatoren
- Massiver und hocheffizienter Kühlkörper
- Weiß beleuchtete, lasergravierte Logo-Glasplatte
- Phasenregelung (GZPA 2SQ)
- Pure Direct Mode (GZPA 2SQ)

Ausstattungsmerkmale



Vorbesserungen an dem Produkt vorzunehmen ohne Kunden darüber zu informieren.
 Wettbewerben entstanden sind. GROUND ZERO behält sich das Recht vor, Änderungen oder die nachweislich durch Überlastung, unsachgemäßen Betrieb oder Installation oder durch die Teilnahme an einer genauen Fehlerbeschreibung erfolgen. Von der Gewährleistung ausgeschlossen sind jedoch Defekte, Absprache und Übergabe in der Originalseparackung sowie mit einer Kopie des originalen Kaufbeleges und Die Gewährleistung entspricht der gesetzlichen Regelung. Eine Bearbeitung kann nur nach vorheriger

Gewährleistung

Partner und den Fachhandel ausgleichen.
 Erst nach einer Reihe an Umfassenden Tests und Prüfungen werden sie an GROUND ZERO und beihaften einige der besten Bauteile, welche für den jeweiligen Einsatz sind.
 Musikliebhabern während vieler Hörsunden fein abgesimmt. Sie werden mit besonderer Sorgfalt produziert Die GZP-SQ-Variante wurden von erfahrenen Sound-Quality Technikern entwickelt und von gesamten Globus und werden für die erzielten Leistungen von zahlreichen Fachzeitschriften überzeugen nicht nur bei weltweit stattfindenden Klangeröffnern, sondern genügen mit herausragenden Fähigkeiten bei der Audiowiedergabe auch höchsten Ansprüchen von High-End Begeisterern.
 Die Subwoofer der Serie setzen sich ihrer Marktführerneue Maßstäbe bei SPL Wettbewerben auf dem Markt, um dieses Ziel der Entwicklung zu erreichen, kommen hierbei aufgrund ihrer technischen, elektronischen und mechanischen Eigenschaften der doppelten Entstehung Produkte.
 Um eines dieser Ziele bei der Entwicklung zu erreichen, kommen hierbei aufgrund ihrer High-End Klange- und Verarbeitungsqualität oder auch extrem hohe Belastbarkeit.
 Produkte, welche zur PLATINUM Serie von GROUND ZERO zählen, beeindrucken durch ihre Entwicklerteam erschaffenen Verteilker.

PLATINUM Series – Ein High-End Erlebnis

Wir wünschen Ihnen viel Freude mit der herausragenden Klangqualität dieses von einem begleisten für die Zusammensetzung der Anlage sowie deren Einbau und Abstimmung den Fachhandel oder eine gesamten Systems sorgfältig aufeinander abgesimmt sind. Daher wird empfohlen, dass dieser seine volle Leistungsfähigkeit nur erreichen kann, wenn alle weiteren Komponenten zum Produkt haben, wenden Sie sich an unser Customer Support.
 Dieses High-End Verteilker für Ihr Fahrzeug. Bitte lesen sie diese sorgfältig durch. Sollten Sie weitere Fragen zum Produkt haben, wenden Sie sich bitte an den Fachhandel oder an unseren Customer Support.
 Der Verteilker ist ein der wichtigsten Bestandteile Ihres Car-Audio-Systems. Bitte bedenken Sie jedoch, dass dieser seine volle Leistungsfähigkeit nur erreichen kann, wenn alle weiteren Komponenten spezialisierte Fachwerkstatt zu konsultieren.

Danke, dass Sie sich für ein GROUND ZERO Produkt entschieden haben und willkommen zu Ihrem neuen Verteilker der PLATINUM Serie.

Einführung

130.com.ua

Deutsch

8 Anschlussanleitung
Bedienungs- und

GZPA 4SQ
GZPA 2SQ

Vervielfacher

PLUTONIUM SERIES

GERMAN ENGINEERING
GRUNDIG ZERO®