

PHONES 0 (800) 800 130 (050) 462 0 130

(063) 462 0 130 (067) 462 0 130

# Internet store of autogoods



SKYPE

km-130

CAR RECEIVERS — Receivers • Media receivers and stations • Native receivers • CD/DVD changers • FM-modulators/USB adapters • Flash memory • Facia plates and adapters • Antennas • Accessories |

CAR AUDIO — Car audio speakers • Amplifiers • Subwoofers • Processors • Crossovers • Headphones • Accessories | TRIP COMPUTERS — Universal computers • Model computers • Accessories |

CAR AUDIO — Car audio speakers • Amplifiers • Subwoofers • Processors • Crossovers • Headphones • Accessories |

CAR AUDIO — Car audio speakers • Amplifiers • CRS — Ruilt in CRS • Ruilt in CRS • CRS — Ruilt in CRS • CRS

- GPS NAVIGATORS Portable GPS Built-in GPS GPS modules GPS trackers Antennas for GPS navigators Accessories | VIDEO DVR TV sets and monitors Car TV tuners Cameras Videomodules Transcoders Car TV antennas Accessories | SECURITY SYSTEMS Car alarms Bike alarms Mechanical blockers Immobilizers Sensors Accessories | OPTIC AND LIGHT Xenon Bixenon Lamps
- LED Stroboscopes Optic and Headlights Washers Light, rain sensors Accessories | PARKTRONICS AND MIRRORS Rear parktronics Front parktronics Combined parktronics Rear-view mirrors Accessories | HEATING AND COOLING Seat heaters Mirrors heaters Screen-wipers heaters Engine heaters Auto-refrigerators Air conditioning units Accessories | TUNING Vibro-isolation
- Noise-isolation Tint films Accessories | ACCESSORIES Radar-detectors Handsfree, Bluetooth Windowlifters Compressors Beeps, loudspeakers Measuring instruments Cleaners Carsits
- Miscellaneous | MOUNTING Installation kits Upholstery Grilles Tubes Cable and wire Tools Miscellaneous | POWER Batteries Converters Start-charging equipment Capacitors
- Accessories | MARINE AUDIO AND ELECTRONICS Marine receivers Marine audio speakers Marine subwoofers Marine amplifiers Accessories | CAR CARE PRODUCTS Additives Washer fluid Care accessories Car polish Flavors Adhesives and sealants | LIQUID AND OIL Motor oil Transmission oil Brake fluid Antifreeze Technical lubricant



In store "130" you can find and buy almost all necessary goods for your auto in Kyiv and other cities, delivery by ground and postal services. Our experienced consultants will provide you with exhaustive information and help you to chose the very particular thing. We are waiting for you at the address

https://130.com.ua

# **MotionProtect Curtain User manual**

Updated August 28, 2024



**MotionProtect Curtain** is a curtain type wireless motion detector. The detector has a narrow horizontal detection angle and is designed for indoor perimeter control: windows, doorways, and other entrances or exits of the guarded facility. Maximum motion detection distance is 15 m.

MotionProtect Curtain integrates into Ajax systems, connecting to a <a href="https://doi.org/nu.2010/journal.org/nu.2010/nu.2010/journal.org/nu.2010/n


An iOS or Android <u>app</u> is used for detector setup. It also notifies the user about any events with push notifications, SMS, or calls (if enabled).

Ajax can be connected to the central monitoring station of a security company.



Connection to ocBridge Plus and uartBridge integration modules is not provided.

## **Functional Elements**



- 1. LED indicator.
- 2. Motion detector lens.
- 3. Hole for fixing the SmartBracket mounting panel with the bundled screw.
- 4. QR code with the device ID. Used to connect to the Ajax system.
- 5. Button to turn on/off the device.
- **6.** Tamper button. Triggers when trying to tear off the detector from the surface or remove it from the mount.
- **7.** SmartBracket mounting plate. To remove the plate, slide it down.

## **Operating Principle**

00:00 00:12





Motion alarms are sent every 5 seconds

To prevent false alarms, MotionProtect Curtain has a Correlation Signal Processing functionality that can be **enabled in the detector's settings**. Once it is active, the detector starts sending alarm states to the hub only if an identical motion signal is registered by both IR sensors. If it is disabled, MotionProtect Curtain sends an alarm state even with one of the two IR sensors triggered.

What is correlation signal analysis and how does it work

# Pairing the Detector with a hub

# Before you start pairing the detector:

- Turn on your hub and check the Internet connection (via Ethernet and/or GSM).
- **2.** Install the <u>Ajax application</u> on your smartphone. Create an account, add your hub to the app, and create at least one room.
- **3.** Check the status of the hub in the app to make sure it is disarmed and is not updating.



Please note that only a user with admin permissions can add devices to the hub

## Pairing MotionProtect Curtain with a hub:

- 1. In the Ajax mobile app, tap Add device.
- 2. Name the device, scan the **QR code** or enter it manually (placed on the back of the detector body or its packaging), select the room for placement, and tap **Add**. The countdown will start.



**3.** Turn on the detector by holding its power button for 3 seconds.



For detection and pairing to occur, the device must be within a hub's wireless coverage (at the same facility). The connection request will be sent to the Hub only once the device turns on.

If the MotionProtect Curtain fails to connect to the hub, it will automatically power down within 6 seconds after turning on. There is no need to turn off the device to retry.

If the MotionProtect Curtain has already been paired with another hub, turn off the detector, and then follow the standard pairing procedure.

After pairing, the detector will appear on the app's hub device list. The frequency of the device status updates depends on the polling interval indicated in the hub's settings (36 seconds by default).

If the detector identifies movement before the system is armed, it will activate not immediately but the next it is polled by the hub.

## **States**

The states display information about the device and its operating parameters. MotionProtect Curtain states are available in the Ajax apps. To view them:

- 1. Sign in to the Ajax app.
- 2. Select the hub if you have several of them or using a PRO app.
- **3.** Go to the **Devices** menu.
- 4. Select MotionProtect Curtain from the list.

| Parameter                | Value   |
|--------------------------|---|
|                          | Detector temperature. It is measured on the processor of the detector and changes gradually.  |
|                          | The acceptable error between the value in the app and the ambient temperature is 2°C.   |
| Temperature              | The value is updated as soon as the detector identifies a temperature change of at least 2°C.                                       |
|                          | You can configure a scenario by temperature to control automation devices.  |
|                          | Learn more  |
| Jeweller Signal Strength | Signal strength between the detector and the hub or the range extender via the Jeweller channel. The recommended value is 2–3 bars. |
| Autogoc                  | ods "130"   |

| Jeweller is a protocol for transmitting  MotionProtect Curtain events and alarms.  |
|--|
| Connection status on the Jeweller channel between the detector and the hub or the range extender:  |
| Online — the detector is connected to the hub or the range extender.   |
| Offline — the detector is not connected to<br>the hub or the range extender. Check the<br>detector connection.   |
| Displays the status of using a radio signal range extender   |
| The battery charge level of the device:  |
| • OK   |
| Battery low  |
| The Ajax apps and the security company will receive appropriate notifications when the batteries are low.  |
| After sending a low battery notification, the detector can work for up to 2 months.  |
| How the battery charge is displayed  |
| Battery life calculator  |
| The status of the detector's tamper that responds to detachment of the device from the surface or opening of the body:   |
| <ul> <li>Open — the detector was removed from the<br/>SmartBracket panel, or the integrity of its<br/>body was compromised. Check the<br/>mounting of the detector.</li> </ul> |
| Closed — the detector is installed on the SmartBracket mounting panel. The body's integrity and the mounting panel wasn't compromised—normal state.  ds "130"                  |
|  |

|                               | Learn more   |
|-------------------------------|--|
| Sensitivity                   | <ul> <li>The sensitivity level of the motion detector:</li> <li>Low</li> <li>Normal</li> <li>High</li> <li>The sensitivity is selected based on the results of the detection zone test.</li> </ul>   |
| Correlation signal processing | Status of the signal correlation processing functionality  |
|                               | When this option is enabled, the detector is always armed.   |
| Always Active                 | This means that the detector will constantly respond to motion and raise alarms regardless of the system arming mode.  |
|                               | Learn more   |
| Permanent Deactivation        | Shows the status of the device permanent deactivation function:  |
|                               | <ul> <li>No — the device operates normally and<br/>transmits all events.</li> </ul>  |
|                               | <ul> <li>Lid only — the hub administrator has<br/>disabled notifications about triggering on<br/>the device body.</li> </ul>   |
|                               | • Entirely — the device is completely excluded from the system operation by the hub administrator. The device does not follow system commands and does not report alarms or other events.  |
|                               | <ul> <li>By number of alarms — the device is<br/>automatically disabled when the number of<br/>alarms is exceeded (specified in the settings<br/>for Devices Auto Deactivation). The<br/>feature is configured in the Ajax PRO app.</li> </ul> |

|   | Learn more  |  |
|---|---|--|
|   |   |  |
| Alarm Reaction                                    |   |  |
| Operating Mode                                    | Shows how the detector reacts to alarms:  |  |
|   | Instant Alarm — the armed detector immediately reacts to a threat and raises the alarm.   |  |
|   | <ul> <li>Entry/Exit — when a delay is set, the armed<br/>device starts the countdown and doesn't<br/>raise the alarm even if triggered until the<br/>countdown ends.</li> </ul>               |  |
|   | <ul> <li>Follower — the detector inherits the delays<br/>from Entry/Exit detectors. However, when<br/>the Follower is triggered individually, it<br/>immediately raises the alarm.</li> </ul> |  |
| Delay When Entering, sec  Delay When Leaving, sec | Delay time when entering: from 5 to 120 seconds.  |  |
|   | Delay when entering (alarm activation delay) is<br>the time the user has to disarm the security<br>system after entering the secured area.  |  |
|   | Learn more  |  |
|   | Delay time when leaving: from 5 to 120 seconds.   |  |
|   | Delay when leaving (arming delay) is the time the user has to leave the secured area after the security system arms.  |  |
|   | Learn more  |  |
| Firmware  | The detector's firmware version.  |  |
| Device ID   | Device identifier. It is also available on the QR code on the detector enclosure and its package box.   |  |
| Device No.  | The number of the device loop (zone).   |  |

## **Detector Setup**

## To change the detector settings in the Ajax app:

- 1. Select the hub if you have several of them or using a PRO app.
- 2. Go to the **Devices** tab.
- **3.** Select MotionProtect Curtain from the list.
- **4.** Go to **Settings** by clicking on the gear icon  $\mathfrak{D}$ .
- **5.** Set the required parameters.
- 6. Click **Back** to save the new settings.

| Setting     | Value   |
|-------------|---|
| Name        | Detector name. It is displayed in the list of hub devices, SMS text, and notifications in the event feed.   |
|             | To change the detector name, click on the text field next to the name.  |
|             | The name can contain up to 12 Cyrillic characters or up to 24 Latin characters.   |
|             | Select the virtual room to which the MotionProtect Curtain is assigned.   |
| Room        | The room name is displayed in the text of SMS and notifications in the events feed of the Ajax apps.  |
| Sensitivity | The motion detector sensitivity level. The choice depends on the type of the object, the presence of probable sources of false alarms, and the specifics of the protected area: |
|             | <ul> <li>Low — there are likely sources of false<br/>alarms in the protected area. For example,<br/>tall bushes.</li> </ul>   |
|             | Autogoods "130"   |


|                                       | <ul> <li>Normal (default value) — recommended value, suitable for most objects. Do not change it if the detector works correctly.</li> <li>High — there is no interference in the protected area; the maximum range of detection and the alarm detection speed are important. For example, if the detector is installed in a narrow passage.</li> </ul> |
|---------------------------------------|---|
|                                       | Before selecting the sensitivity level, conduct the <b>detection zone test</b> . If during the test, the detector doesn't react to movement in 5 cases out of 5, the sensitivity should be increased.   |
| Correlation signal processing         | When this option is enabled and motion is detected, MotionProtect Curtain additionally analyzes the received signals from two infrared sensors to protect against false alarms.  Learn more   |
| Always Active                         | When this option is enabled, the detector is permanently in armed mode.  This means that the detector will constantly respond to motion and raise alarms regardless of the system arming mode.  Learn more  |
| Alarm LED indication                  | Allows you to disable the flashing of the LED indicator during an alarm. Available for devices with firmware version 6.53.1.1 or higher  How to find the firmware version or the ID of the detector or device   |
| Alert with a siren if motion detected | If active, <b>sirens</b> added to the system are activated if the motion is detected  |
| Alarm F                               | Reaction  |
| Operating Mode                        | Specify how this device will react to alarms:   |
| Autogod                               | ods "130"   |

|                                     | <ul> <li>Instant Alarm — the armed detector immediately reacts to a threat and raises the alarm.</li> <li>Entry/Exit — when a delay is set, the armed device starts the countdown and doesn't raise the alarm even if triggered until the countdown ends.</li> <li>Follower — the detector inherits the delays from Entry/Exit detectors. However, when the Follower is triggered individually, it immediately raises the alarm.</li> </ul> |
|-------------------------------------|---|
| Delay When Entering, sec            | Delay time when entering: from 5 to 120 seconds.  Delay when entering (alarm activation delay) is the time the user has to disarm the security system after entering the secured area.  Learn more  |
| Delay When Leaving, sec             | Delay time when leaving: from 5 to 120 seconds.  Delay when leaving (arming delay) is the time the user has to leave the secured area after the security system arms.  Learn more   |
| Arm in Night Mode                   | If active, the detector becomes armed once system enters <b>Night Mode</b>  |
| Night Mode Delay When Entering, sec | Delay time when entering in <b>Night Mode</b> : 5 to 120 seconds.  Delay when entering (alarm activation delay) is the time the user has to disarm the security system after entering the premises. <b>Learn more</b>   |
| Night Mode Delay When Leaving, sec  | Delay time when leaving in <b>Night Mode</b> : 5 to 120 seconds.  |
| Autogod                             | ods "130"   |

|                               | Delay when leaving (arming delay) is the time  |
|-------------------------------|--|
|                               | the user has to leave the premises after arming.   |
|                               | Learn more   |
| Jeweller Signal Strength Test | Switches the detector to the Jeweller signal strength test mode.   |
|                               | The test allows you to check the signal strength between the detector and the hub or the range extender over the Jeweller wireless data transfer protocol to determine the optimal installation location for the device. |
|                               | The recommended value is 2–3 bars.   |
|                               | Learn more   |
| Detection Zone Test           | Switches the detector to the detection zone test mode.   |
|                               | The test enables users to check how the detector responds to movement and to determine the optimal installation location.  |
|                               | If, during the test, the detector does not respond to motion in 5 cases out of 5, increase the sensitivity or change the detector's location.  |
|                               | Learn more   |
|                               | Switches the detector to the signal attenuation test mode.   |
| Signal Attenuation Test       | During the test, the transmitter power is decreased or increased to simulate a change in the environment to test the communication stability between the detector and the hub.   |
|                               | Available in detectors with firmware version 3.50 or later.  |
|                               | Learn more   |
| Permanent Deactivation        | Allows the user to disable the device without removing it from the system.   |
| Autogoo                       | <sub>ds</sub> Thyge options are available:   |

|               | • No.  |  |
|---------------|--|--|
|               | Entirely — the device does not execute system commands and does not participate in automation scenarios, and the system ignores alarms and other device notifications. |  |
|               | Lid only — the system ignores the detector tamper triggering notifications.  |  |
|               | More about permanent deactivation  |  |
|               | The system can also automatically deactivate devices when the preset number of alarms is exceeded.   |  |
|               | More about auto deactivation   |  |
| User Guide    | Opens the MotionProtect Curtain User Guide in the Ajax app.  |  |
| Unpair Device | It unpairs the detector: disconnects it from the hub, and deletes its settings.  |  |

# **Detector Indication**



The MotionProtect Curtain indicator LED may turn red or green, depending on the status of the device.

## Indication when pressing the power button

| Event  | Indication                                     |
|--|--|
| The power button is pressed (detector is on) | Lights up red while the button is held         |
| Turning on                                   | Lights up green while the device is turning on |
| Turning off                                  | Lights up red, then flashes three times        |

#### **Active detector indication**

| Event                              | Indication                            | Note   |
|------------------------------------|---------------------------------------|--|
| Connecting the detector to the hub | Lights up green for a few seconds     |  |
| Hardware error                     | Flashes red continuously              | The detector needs to be repaired, contact support                       |
| Motion or tamper alarm triggered   | Lights up green for about 1 second    | •  |
| Battery replacement needed         | Smoothly lights up green and goes off | For battery replacement procedure, see <b>Battery</b> replacement manual |

# **Integrity Testing**

Ajax systems can run tests to verify the integrity of connected devices.

The tests start instantly, but no later than within 36 seconds by default. The test start time depends on the detector polling interval setting (see the **Jeweller** section in the Hub settings).

**Jeweller Signal Strength Test** 

**Detection Zone Test** 


**Signal Attenuation Test** 

## **Detector Placement**



The effectiveness of the security system depends on detector placement. Choosing a location to install MotionProtect Curtain, consider the direction of the light filter and obstacles that may affect the detector's field of view and the radio signal transmission.

Consider the detection range as well as the beam width when installing the detector. Incorrect device placement can lead to false alarms or improper operation of the device.



Horizontal and vertical detector's angles of view

| Detection range | Beam width  |
|-----------------|-------------|
| 3 meters        | 0.3 meters  |
| 6 meters        | 0.6 meters  |
| 9 meters        | 0.9 meters  |
| 12 meters       | 1.25 meters |
| 15 meters       | 1.55 meters |



The device developed only for indoor use.

#### Do not install the detector:

- Outside the premises (outdoors)
- · In front of the windows within reach of direct sunlight
- Opposite of the objects that rapidly change temperature (e.g., electric and gas heaters)
- Opposite of the moving objects having a temperature close to that of the human body (curtains swaying above a heating radiator)
- In places with fast air circulation (near fans, open windows or doors)
- Near metal objects and mirrors that cause the attenuation or interfere with radio signals
- Within any premises with the temperature and humidity beyond the permitted range
- Closer than 1 m to a hub

If the detector keeps reacting to interference and raising false alarms, but it is impossible to install it anywhere else, the Correlation Signal Processing can be enabled in the settings.



Please note that if the **Correlation Signal Processing** is enabled, the range of motion detection is reduced depending on the detector sensitivity chosen


| Sensitivity | Motion detection range w/ Signal<br>Correlation Processing * | Motion detection range w/o Signal Correlation Processing * |
|-------------|--|--|
| Low         | Up to 6 m  | Up to 11 m   |
| Normal      | Up to 7 m  | Up to 13 m   |
| High        | Up to 8 m  | Up to 15 m   |

\*at an ambient temperature of 23°C

If possible, avoid situations where the detector identifies movement at a longer distance than required. The best place to install it is within an enclosed place. For instance, to detect movement in an archway, install the detector in it. This way, the detector will be triggered only by a person that enters it.



To prevent the detector from reacting to domestic animals, install it upside down, leaving space for the free movement of animals below the detection zone.



The placement of a MotionProtect Curtain also depends on the distance to a hub and whether there are any obstacles between the devices that may hinder the radio signal, e.g., walls, floor deck, or large objects in the room.

Check the signal strength at the placement location. If you have a signal level of one bar, there is no guarantee of the security system's stable operation. Take all necessary precautions to ensure maximum signal level. At least try moving the device—even 20 cm can make a difference.

If after moving the device still has a low or unstable signal strength, use a <u>radio</u> signal range extender.



The detector's light filter should be directed perpendicularly to the expected entry path to the room!

Make sure that no furniture, home plants, vases, decorative or glass structures are blocking the detector's field of view.



We recommend installing the detector at a height of 2.4 m

Installing the detector at any other height will narrow the detection zone, affecting the quality of motion detection.

Keep in mind that MotionProtect Curtain does not detect movement behind the glass. Therefore, do not install the detector in places where glass structures may block its range of view, e.g., in places where an open window may obstruct the device's field of view.

#### **Detector Installation**


Before installing the detector, make sure that you have chosen an appropriate location as indicated in this manual.

#### There are two options for installing MotionProtect Curtain:

• directly to a surface



• to the included bracket.



#### Installation procedure:

- Attach the SmartBracket panel or a bracket to the surface with the included screws or other equally reliable fasteners. Screw the SmartBracket panel onto the included bracket.
- 2. Attach the detector to the SmartBracket attachment panel.
- **3.** Mount the detector on the SmartBracket attachment panel using a screw.

The double-sided adhesive tape should be used only for the temporary installation of the detector. It will dry out eventually, becoming unable to reliably hold the detector and possibly causing false alarms in the security system. The fall of the device may also result in its damage.

If the detector's LED fails to light up after the device is attached to the SmartBracket, check the tamper status in the Ajax app and then check if it fits tightly onto the attachment panel. If you try to detach the detector from the surface or the panel, you will receive a notification.



Having installed the detector, run the <u>Detection Zone Test</u>. In case of incorrect operation, the detector needs to be relocated.

## **Detector Care and Battery Replacement**

Check the integrity of the MotionProtect Curtain detector regularly. Clean the detector body from dust, spider webs, and other contaminations as they appear. Use soft dry cloth suitable for equipment care.

Do not clean the detector with any substances containing alcohol, acetone, gasoline, or any other active solvent. Wipe the lens carefully and gently—any scratches on the plastic may reduce the detector's sensitivity.

The pre-installed battery ensures up to 3 years of autonomous operation (at a polling interval of 3 min). If the detector battery is nearly depleted, the security system will send a notification, and the LED will smoothly light up and go out when the detector detects any motion or if the tamper is activated.

How long Ajax devices operate on batteries, and what affects this

**Battery replacement** 

# **Technical specifications**

All technical specifications of MotionProtect Curtain Jeweller

Compliance with standards

## Warranty

The warranty for the Limited Liability Company "Ajax Systems Manufacturing" products is valid for 2 years after the purchase and does not apply to the pre-installed battery.

If the device does not work correctly, contact our customer support first—in 50% the cases, technical issues can be solved remotely!

The full text of the warranty

User Agreement

Technical support: support@ajax.systems



Subscribe to the newsletter about safe life. No spam

Email Subscribe