PHONES 0 (800) 800 130 0 (800) 800 130 130 (050) 462 0 130 063) 462 0 130 (067) 462 0 130 COM.UA

CAR RECEIVERS — Receivers • Media receivers and stations • Native receivers • CD/DVD changers • FM-modulators/USB adapters • Flash memory • Facia plates and adapters • Antennas • Accessories | CAR AUDIO — Car audio speakers • Amplifiers • Subwoofers • Processors • Crossovers • Headphones • Accessories | TRIP COMPUTERS — Universal computers • Model computers • Accessories | GPS NAVIGATORS — Portable GPS • Built-in GPS • GPS modules • GPS trackers • Antennas for GPS navigators • Accessories | VIDEO — DVR • TV sets and monitors • Car TV tuners • Cameras • Videomodules • Transcoders • Car TV antennas • Accessories | SECURITY SYSTEMS — Car alarms • Bike alarms • Mechanical blockers • Immobilizers • Sensors • Accessories | OPTIC AND LIGHT — Xenon • Bikenon • Lamps • LED • Stroboscopes • Optic and Headlights • Washers • Light, rain sensors • Accessories | PARKTRONICS AND MIRRORS — Rear parktronics • Combined parktronics • Rear-view mirrors • Accessories | HEATING AND COOLING — Seat heaters • Mirrors heaters • Screen-wipers heaters • Engine heaters • Air - orditioning units • Accessories | TUNING — Vibro-isolation • Noise-isolation • Tint films • Accessories | ACCESSORIES — Radar-detectors • Handsfree, Bluetooth • Windowlifters • Compressors • Beeps, loudspeakers • Mearing instruments • Cleaners • Carsits • Miscellaneous | MOUNTING — Installation kits • Upholstery • Grilles • Tubes • Cable and wire • Tools • Miscellaneous | POWER — Batteries • Converters • Start-charging equipment • Capacitors • Accessories | MARINE AUDIO AND ELECTRONICS — Marine receivers • Marine audio speakers • Marine subwoofers • Marine amplifiers • Accessories | CAR CARE PRODUCTS — Additives • Washer fluid • Care accessories • Car polish • Flavors • Adhesives and sealants | LIQUID AND OIL — Motor oil • Transmission oil • Brake fluid • Antifreez • Technical lubricant



In store "130" you can find and buy almost all necessary goods for your auto in Kyiv and other cities, delivery by ground and postal services. Our experienced consultants will provide you with exhaustive information and help you to chose the very particular thing. We are waiting for you at the address

https://130.com.ua





ENGLISH/РУССКИЙ

www.blackvue.com

BLACKVUE

DR750X-1CH

For manuals, customer support and FAQs go to <u>www.blackvue.com</u> Руководства, служба технической поддержки и часто задаваемые вопросы представлены на сайте <u>www.blackvue.com</u>

Important safety information

For user safety and to avoid property damage, read through this manual and follow these safety instructions to use the product correctly.

• Do not disassemble, repair, or modify the product yourself.

Doing so may cause fire, electric shock, or malfunction. For internal inspection and repair, contact the service center.

• Do not adjust the product while driving.

Doing so may cause an accident. Stop or park your car in a safe place before installing and setting up the product.

Do not operate the product with wet hands.

Doing so may cause electric shock.

- If any foreign matter gets inside the product, detach the power cord immediately. Contact the service center for repair.
- Do not cover the product with any material.

Doing so may cause external deformation of the product or fire. Use the product and peripherals in a well-ventilated location.

- If the product is used outside the optimal temperature range (-20°C 85°C / -4°F 185°F), performance can decline or malfunctions may occur.
- When entering or exiting a tunnel, when directly facing into bright sunlight, or when
 recording at night without lighting the quality of recorded video may deteriorate.
- If the product is damaged or the power supply is cut due to an accident, video may not be recorded.
- Do not remove the microSD card while the microSD card is saving or reading data.
- The data can be damaged or malfunctions may occur.

FCC Compliance Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protections against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to ty to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio, TV technician for help.
- Only shielded interface cable should be used.

Finally, any changes or modifications to the equipment by the user not expressly approved by the grantee or manufacture could void the user's authority to operate such equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation of this device.

FCC ID: YCK-DR750X-2CH

4 BLACKVUE

CAUTION

Any changed or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

There is a risk of explosion if the battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

CE WARNING

- Changes and modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- It is desirable that it be installed and operated with at least 20cm or more between the radiator and a person's body (excluding extremities: hand, wrists, feet, and ankles).

Disposal of your BlackVue dashcam



- All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities. Contact local authorities to learn about disposal and recycling options available in your area.
- The correct disposal of your BlackVue dashcam will help prevent potential negative consequences for the environment and human health.
- For more detailed information about disposal of your BlackVue dashcam, please contact your city office, waste disposal service or the shop where you purchased the product.

ICC Compliance

This Class [B] digital apparatus complies with Canadian ICES-003.

This radio transmitter has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

- IC Warning

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicable aux appreils radio exempts de license.

L'exploitation est autoriséee aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, méme si le brouillage est susceptible d'encompromettre le fonctionnement.

6 BLACKVUE

In the box

Check the box for each of the following items before installing the BlackVue dashcam.



At a glance

The following diagrams explain each part of the BlackVue dashcam.

Front camera



8 BLACKVUE





STEP 1 Install and power up

Install the front camera behind the rear view mirror. Remove any foreign matter and clean and dry the windshield before installation.







Warning

• Do not install the product in a location where it can obstruct the driver's field of vision.

(A) Turn off the engine. Open the cover of the microSD card slot, gently push the card into the slot until it locks into place and close the cover.



(R) Peel off the protective film from the double-sided tape and attach the front camera to the windshield behind the rear-view mirror.



Adjust the angle of the lens by rotating the body of the front camera. We recommend pointing the lens slightly downwards (≈10° below horizontal), so as to record video with a 6:4 road to background ratio.



- Connectivity Module (Optional): Connect the connectivity module to the front camera and attach it to the edge of the window. Use the pry tool to tuck in the cable.
- E Plug the cigarette lighter power cable into the cigarette lighter socket and the front camera. Skip to () for Hardwiring Power Cable setup.
- Use the pry tool to lift the edges of the windshield trim/molding and tuck in the power cord.



- G Turn on the engine. The BlackVue dashcam will power up and start recording. Video files are stored on the microSD card.
- Turn off the engine. The dashcam will automatically stop recording and power down. To record in parking mode while the engine is off please connect the Hardwiring Power Cable (included in the box) or install a Power Magic Battery Pack (sold separately). A Hardwiring Power Cable uses the automotive battery to power your dashcam when the engine is off. A low voltage power cut-off function and a parking mode timer to protect the automotive battery from discharge is installed in the device. Settings can be changed in the BlackVue App or Viewer.

12 BLACKVUE

Locate the fuse box to connect the hardwiring power cable.

ENGLISH

📝 Note

- Location of the fuse box differ by manufacturer or model. For details, refer to the vehicle owner's manual.
- (1) After removing fuse panel cover, find a fuse that powers on when engine is turned on(ex.cigarette lighter socket, audio, etc) and another fuse that remains powered on after the engine is turned off (ex.hazard light, interior light). Connect the ACC+ cable to a fuse that powers on after engine start, and BATT+ cable to a fuse that remains powered on after engine is turned off.

📝 Note

- To use battery saver feature, connect the BATT+ cable to the hazard light fuse. Functions of fuse differ by manufacturer or model. For details refer to the vehicle owner's manual.
- 1-2 Connect the GND cable to metal ground bolt.



 (\mathbf{J})

Connect the power cable to the DC in terminal of the front camera. BlackVue will power up and start recording. Video files are stored on the microSD card.



 When you run the dashcam for the first time the firmware is automatically loaded onto the microSD card. After the firmware has been loaded onto the microSD card you can customize settings using BlackVue Viewer on a computer.

14 BLACKVUE

STEP 2 Playback

- Search for the BlackVue app in the Google Play Store or Apple App Store and install it on your smartphone.
- B "Pair" your smartphone with the BlackVue dashcam via direct Wi-Fi:
 - (i) Press the Wi-Fi button once to turn on Wi-Fi.
 - (ii) Go to your smartphone's Settings then select Wi-Fi, and make sure Wi-Fi is turned on.



- (iii) Choose your BlackVue dashcam from the network list. The dashcam's default SSID begins with its model number (e.g. BlackVue750X.******).
- (iv) Enter the password and tap join.
 - * To find the default Wi-Fi password, unplug the cables and remove the front camera from its mount. The default Wi-Fi SSID, password and cloud code are printed on the dashcam's connectivity details label.

(v) Open the BlackVue app and select WI-FI.



C Select the video file you want to play from the video list.

🗐 Note

- Direct Wi-Fi lets you connect your smartphone to your dashcam via Wi-Fi within a range of 10m.
- For quick playback and download of the recordings, you can select the "Quick play file" option from App settings.
- All image shown are for illustration purposes only. Actual App may differ from images shown.

Playing video files on your **computer** (Windows/macOS)

A Remove the microSD card from the dashcam.



(B) Insert the card into the microSD card reader and connect it to a computer.



© Download BlackVue Viewer program from <u>www.blackvue.com</u> > Support > Downloads and install it on your computer.

D Run BlackVue Viewer. To play, select a video and click on the play button or double click the selected video.



Windows/macOS Viewer

📝 Note

 All images shown are for illustration purpose only. Actual program may differ from images shown.

STEP 3 Changing dashcam's time zone, Wi-Fi password and other settings.

The dashcam's time zone is initially set to (GMT-11). To display the correct time please select your time zone.

- Using your smartphone (Android/iOS)
- (A) "Pair" your smartphone with the BlackVue dashcam via direct Wi-Fi (for details see STEP 2'Playing video files on your smartphone').
- (B) Open the BlackVue app and select WI-FI.
- C Tap the 🗘 button to access the Firmware settings menu.



- (i) Select Firmware settings > Basic > Time.
 - Select your time zone to auto-sync with GPS time or you can set the time and date manually after enabling Manual time setting.

(E) Go back to the Firmware settings menu and configure other desired settings. Settings that can be changed include Wi-Fi SSID & password, image quality, sensitivity settings, voice recording on/off, speed unit (km/h, MPH, off), LEDs on/off, voice guidance volume, Cloud settings etc. Once settings are configured, tap and tap Save.



Changing the dashcam's time zone and other firmware settings on your computer (Windows/macOS)

Run BlackVue Viewer program after connecting dashcam's microSD card to your computer. Click on the the button to open the BlackVue settings panel.



Settings that can be changed include Wi-Fi SSID & password, image quality, sensitivity settings, voice recording on/off, speed unit (km/h, MPH, off), LEDs on/off, voice guidance volume, Cloud settings etc.

For more information about changing the settings in BlackVue Viewer, please download the manual from <u>www.blackvue.com</u> > **Support** > **Downloads**.

STEP 4 Connect to BLACKVUE CLOUD (optional)

If you don't have a mobile Wi-Fi hotspot, Blackvue connectivity module or if you don't want to use the BLACKVUE CLOUD service, you can skip this step.

If you have a mobile Wi-Fi hotspot (also known as a portable Wi-Fi router), BlackVue connectivity module (CM100LTE), a car-embedded wireless internet network or a Wi-Fi network near your car, you can use the BlackVue app to connect to BLACKVUE CLOUD and see in real-time where your car is and the dashcam's live video feed.

For more information about using the BlackVue app, please download the Cloud Manual from <u>www.blackvue.com</u> > **Support** > **Downloads**.

(A) Create an account

- (i) Open the BlackVue app.
- (ii) Tap the button in the top-left corner and select Create account.
- (iii) Enter your name, e-mail address and choose a password. Re-enter your password and press **Sign up**.
- (iv) You will receive an e-mail. Click the link in the email to finish creating your account.

(B) Register your dashcam with your account

- (i) In the BlackVue app select CLOUD and login to your account.
- (ii) Tap Yes to enable push notifications (this setting can be adjusted at any time later).
- (iii) Select Register new camera.
- (iv) Register your camera using one of the following methods:

ENGLISH

QR Code: Press **Scan QR Code** and line up the QR Code on your smartphone's screen.



or

Manual registration: Enter your camera's Serial number and Cloud code and press Register.

C Connect your BlackVue dashcam to a Wi-Fi hotspot for Cloud connectivity

- (i) Make sure your BlackVue dashcam and mobile Wi-Fi hotspot are on.
- (ii) "Pair" your smartphone with the BlackVue dashcam via direct Wi-Fi (for details see STEP 2 'Playing video files on your smartphone')

(iii) Open the BlackVue app. Select WI-FI > 🗱 > Firmware settings > CLOUD.



- (iv) Ensure Enable Cloud service is on. Select Cloud service hotspot settings.
- (v) Choose your Wi-Fi hotspot from the list. Enter the password and tap OK.



Note

- Up to 3 Wi-Fi hotspot SSIDs can be saved (e.g. home, portable hotspot and work).
- The BlackVue DR750X dashcam is not compatible with 5GHz wireless networks.

(vi) Go back to the Firmware settings menu, tap < and tap Save.



After rebooting, your dashcam will automatically establish internet connection. If internet connection was not established, please ensure Wi-Fi information was inserted correctly.

Select CLOUD from the main screen to access all of the Cloud features.

📝 Note

 If LTE and Wi-Fi hotspot is available for internet connection, Wi-Fi hotspot will be in priority. If LTE connection is preferred at all times, please remove Wi-Fi hotspot information.

D Connect your BlackVue dashcam to Cloud connectivity (Using CM100LTE)

Make sure your BlackVue dashcam and connectivity module is connected. Then, follow the below steps for SIM registration.

- (i) Locate the SIM card slot. Unscrew the bolt from SIM slot cover. Then, unmount the SIM slot by using a SIM eject tool. Insert SIM in the SIM slot. Mount the SIM slot back in the connectivity module, then, screw the bolt to hold SIM slot cover.
- (ii) "Pair" your smartphone with the BlackVue dashcam via direct Wi-Fi.
- (iii) Open the BlackVue app and select WI-FI > 1.

DR750X-1CH 25

Autogoods "130"



- (iv) Configure the APN settings to activate the SIM card. For detailed information, please check "SIM activation guide" in the packaging box or visit BlackVue Help Center: <u>www.helpcenter.blackvue.com</u> -> LTE connectivity guide.
- (v) Once your dashcam is connected to the internet, you can go to the CLOUD menu to use BlackVue Cloud features.

📝 Note

- For full details, refer to the "SIM activation guide" that is included in the CM100LTE package.
- To use the BlackVue Cloud Service, SIM card must be properly activated for Internet access via LTE network.
- When the dashcam is connected to internet, you can use BlackVue Cloud features such as remote Live View and Video playback, Real-time location, push notification, Auto-upload, remote Firmware update etc. on BlackVue app and PC Viewer.
- Some Cloud features may not work when surrounding temperature is high or/and LTE speed is slow.
- For more information about using the BlackVue app, please download the Cloud Manual from <u>www.blackvue.com</u> > Support > Downloads.

Tips for optimal performance

For stable operation of the dashcam, it is recommended to format the microSD card once a month.

Format using BlackVue Viewer (Windows):

Download **BlackVue Windows Viewer** from <u>www.blackvue.com</u> > **Support** > **Downloads** and install it on your computer. Insert the microSD card into the microSD card reader and connect the reader to your computer. Launch the copy of BlackVue Viewer that is installed on your computer. Click the Format button, select the card drive and click OK.

Format using BlackVue Viewer (macOS):

Download **BlackVue Mac Viewer** from <u>www.blackvue.com</u> > **Support** > **Downloads** and install it on your computer. Insert the microSD card into the microSD card reader and connect the reader to your computer. Launch the copy of BlackVue Viewer that is installed on your computer. Click the Format button and select the microSD card from the list of drives in the left frame. After selecting your microSD card select the Erase tab in the main window. Select "MS-DOS (FAT)" from the Volume Format drop-down menu and click Erase.

Only use official BlackVue microSD cards. Other cards may have compatibility issues.

Regularly upgrade the firmware for performance improvements and updated features. Firmware updates will be made available for download at <u>www.blackvue.com</u> > Support > Downloads.

Customer Support

For customer support, manuals and firmware updates please visit <u>www.blackvue.com</u> You can also email a Customer Support expert at <u>cs@pittasoft.com</u>

Product specifications:

Model Name	DR750X-1CH		
Color/Size/Weight	Black / Width 118.5 mm x Height 36 mm / 103 g		
Memory	microSD Card (32 GB / 64 GB / 128 GB / 256 GB)		
Recording Modes	Normal recording, Event recording (when impact is detected in normal and parking mode), Manual recording and Parking recording (when motion is detected) * When using Hardwiring Power Cable, ACC+ will trigger parking mode. When using other methods, G-sensor will trigger parking mode.		
Camera	STARVIS™ CMOS Sensor (Approx. 2.1 M Pixel)		
Viewing Angle	Diagonal 139°, Horizontal 116°, Vertical 61°		
Resolution/ Frame Rate	Full HD @60fps * Frame rate may vary during Wi-Fi streaming.		
Image Quality	Highest (Extreme), Highest, High, Normal		
Video Compression Mode	MP4		
Wi-Fi	Built-in (802.11 b.g.n)		
GPS	Built-in (Dual Band : GPS, GLONASS)		
Bluetooth	Built-in (V2.1+EDR/4.2)		
LTE	External		
Microphone	Built-in		

28 BLACKVUE

Speaker (Voice Guidance)	Built-in	ENGLISH
LED Indicators	Recording LED, GPS/BT LED, LTE/Wi-Fi LED, Front Security LED, Proximity Sensing indicator LED	
Button	Wi-Fi button: * Press once to turn on/off Wi-Fi. Proximity sensor: Touching the proximity sensor turns on/off audio recording or triggers manual recording depending on the firmware settings.	
Sensor	3-Axis Acceleration Sensor	
Backup Battery	Built-in super capacitor	
Input Power	DC 12V-24V (DC Plug (Ø3.5 x Ø1.35)) to Wires (Black: GND / Yellow: B+ / Red: ACC)	
Power Consumption	Normal Mode (WiFi On / GPS On) : 275mA / hour Normal Mode (WiFi Off / GPS On) : 240mA / hour Parking Mode (WiFi On / GPS Off) : 220mA / hour Parking Mode (WiFi Off / GPS Off) : 185mA / hour * Actual power consumption may vary depending on use conditions and environment.	
Operation Temperature	-20 °C – 85 °C (-4 °F – 185 °F)	
Storage Temperature	-20 °C – 90 °C (-4 °F – 194 °F)	
High Temperature Cut-Off	Approx. 85 °C (185 °F)	
Certifications	FCC, CE, RoHS, Telec, WEEE, IC	

DR750X-1CH 29

Autogoods "130"

Software	BlackVue Viewer * Windows 7 or higher and Mac Yosemite OS X (10.10) or higher
Application	BlackVue Application (Android 5.0 or higher, iOS 9.0 or higher)
Others	Adaptive Format Free File Management System

* STARVIS is a trademark of Sony Corporation.

Комплектация изделия

Перед установкой видеорегистратора BlackVue проверьте комплектацию изделия.



🕨 Внешний вид

На схемах ниже представлены все части видеорегистратора BlackVue.

Передняя камера



32 BLACKVUE



Табличка с серийным номером

Индикатор датчика близости

Загорается, когда срабатывает датчик близости.



Датчик близости:

Коснитесь датчика или проведите пальцем на расстоянии 20 мм от него, чтобы запустить пользовательскую функцию.

Доступные опции:

- Включение/выключение записи звука (по умолчанию)
- Включение записи вручную
- Откл.



ШАГ 1 Установка и подключение питания

Установите переднюю камеру над зеркалом заднего вида. Перед установкой удалите все посторонние предметы с ветрового стекла, очистите его и протрите насухо.



🕨 Внимание

 Не устанавливайте видеорегистратор в месте, где он будет загораживать водителю обзор.

Остановите двигатель. Откройте крышку слота карты microSD, аккуратно вставьте карту в слот, пока она не займет нужное положение, а затем закройте крышку.



В Снимите защитную пленку с двусторонней клейкой ленты и закрепите переднюю камеру над зеркалом заднего вида.



Откорректируйте угол объектива, вращая корпус передней камеры. Рекомендованное положение камеры — с небольшим наклоном вниз (на ≈10° ниже горизонтального положения). Это позволяет записывать видео с соотношением заднего плана и дорожного полотна 6:4.



- Соединительный модуль (дополнительно): Подключите соединительный модуль к передней камере и прикрепите его к краю окна. Используйте рычажок, чтобы проложить кабель.
- Вставьте кабель питания в разъем прикуривателя и подключите другой конец кабеля к передней камере. Перейдите к (), чтобы подключить силовой кабель.
- С помощью специального рычажка приподнимите края резинового уплотнителя по краю ветрового стекла и подоткните под него кабель питания.



- G Запустите двигатель. Видеорегистратор BlackVue включится и начнет запись. Файлы видеозаписи сохраняются на карте microSD.
- Остановите двигатель. Видеорегистратор автоматически остановит запись и выключен, подключите силовой кабель (включен в комплект поставки) или установите Power Magic Battery Pack (приобретается отдельно). Силовой кабель используется для подключения видеорегистратора к аккумулятору автомобиля, когда двигатель выключен. Чтобы аккумулятор не разрядился полностью, на устройстве предусмотрены функция отключения питания при низком напряжении и таймер режима парковки. Настройки могут быть изменены в приложении BlackVue или Viewer.
- 36 BLACKVUE

Определите местонахождение блока предохранителей, чтобы подключить силовой кабель.

🎽 Примечание

 Местоположение блока предохранителей зависит от бренда и модели автомобиля. Для получения дополнительной информации обратитесь к руководству владельца транспортного средства. РУССКИЙ

После снятия крышки блока предохранителей найдите предохранитель, который находится по напряжением, когда двигатель включен (это могут быть цепи, питающие прикуриватель, аудиосистему и т. д.), а также другой предохранитель, который подает питание после отключения двигателя на такие цепи, как аварийный свет и внутреннее освещение). Подключите клемму АСС+ кабеля к предохранителю, который находится под напряжением после запуска двигателя, а клемму BATT+ кабеля подключите к предохранителю, который остается под напряжением после выключения двигателя.



/ Примечание

 Чтобы использовать функцию защиты аккумулятора, подключите клемму ВАТТ+ кабеля к предохранителю цепи аварийных фонарей.
 Функции предохранителей зависят от бренда и модели автомобиля.
 Для получения дополнительной информации обратитесь к руководству владельца транспортного средства.

DR750X-1CH 37

Autogoods "130"

(1)-(2)

 (\mathbf{J})

Прикрутите клемму кабеля GND к металлическому болту заземления.



Подключите кабель питания к порту DC передней камеры. Видеорегистратор BlackVue включится и начнет запись. Файлы видеозаписи сохраняются на карте microSD.

🗐 Примечание

 При первом запуске видеорегистратора программная прошивка автоматически загружается на карту microSD. После загрузки программной прошивки на карту microSD можно управлять настройками видеорегистратора через программу BlackVue Viewer на ПК.

ШАГ 2 Воспроизведение

- Воспроизведение файлов видеозаписи на смартфоне (Android/iOS)
- Найдите приложение BlackVue в магазине Google Play или App Store и установите его на своем смартфоне.



- (B) Выполните сопряжение смартфона с видеорегистратором BlackVue с помощью Wi-Fi Direct. Для этого:
 - (i) Однократно нажмите кнопку Wi-Fi, чтобы включить Wi-Fi.
 - (ii) перейдите в меню Настройки в вашем смартфоне, выберите Wi-Fi и убедитесь, что сеть Wi-Fi включена.



- (iii) Выберите видеорегистратор BlackVue в списке сетей. SSID видеорегистратора по умолчанию начинается с номера модели (например, BlackVue750X-******).
- (iv) Введите пароль и нажмите «Присоединиться».
 - Чтобы узнать пароль Wi-Fi по умолчанию, отключите кабели и снимите переднюю камеру с держателя. SSID и пароль Wi-Fi по умолчанию, а также код Cloud указаны на табличке сведений о подключении видеорегистратора.

(v) Откройте приложение BlackVue и выберите WI-FI.



🔘 Выберите в списке файл видеозаписи, который вы хотите воспроизвести.

🗐 Примечание

- Вы можете подключить смартфон к видеорегистратору с помощью Wi-Fi в радиусе 10 метров.
- Для быстрого воспроизведения и загрузки записей можно выбрать опцию «Быстрое воспроизведение файла» в настройках приложения.
- Все иллюстрации приведены только для примера. Фактический интерфейс приложения может отличаться.

Bocпроизведение видеозаписей на **ПК** (Windows/Mac)

(A) Извлеките карту microSD из видеорегистратора.



Вставьте карту в устройство для считывания карт microSD и подключите устройство к ПК.



Загрузите программу BlackVue Viewer по адресу <u>www.blackvue.com</u> > Support > Downloads и установите ее на компьютер.

Запустите BlackVue Viewer. Для воспроизведения выберите видео и нажмите кнопку воспроизведения либо дважды щелкните видео.



Viewer для Windows/macOS

📝 Примечание

 Все иллюстрации приведены только для примера. Фактический внешний вид программы может отличаться от приведенных здесь изображений.

ШАГ 3 Изменение часового пояса видеорегистратора, пароля Wi-Fi и других настроек.

Часовой пояс видеорегистратора исходно установлен на GMT-11. Чтобы время отображалось корректно, выберите свой часовой пояс.

- Использование смартфона (Android/iOS)
- Выполните сопряжение смартфона с видеорегистратором BlackVue через Wi-Fi Direct (подробнее см. ШАГ 2 «Воспроизведение файлов видеозаписи на смартфоне»).
- (B) Откройте приложение BlackVue и выберите WI-FI.
- 🔘 Коснитесь кнопки 🗱, чтобы войти в меню настроек программной прошивки.



- (i) Выберите Настройки прошивки > Базовые > Время.
 - Выберите часовой пояс для автоматической синхронизации с временем GPS или задайте время и дату вручную после активации параметра Настройка времени вручную.

DR750X-1CH 43

Autogoods "130"

Перейдите в меню настроек прошивки и настройте другие необходимые параметры.

Вы можете изменять такие параметры, как имя и пароль сети Wi-Fi, качество изображения, настройки чувствительности, запись звука вкл / выкл, единицы скорости (км/ч, миль/ч, выкл.), включение/выключение индикаторов, громкость голосового управления, настройка Cloud и др.

После настройки параметров нажмите </ и выберите «Сохранить».



44 BLACKVUE

Изменение часового пояса видеорегистратора и других настроек прошивки на компьютере (Windows/macOS)

Запустите программу BlackVue Viewer после подключения карты microSD видеорегистратора к компьютеру. Нажмите кнопку 😋, чтобы открыть панель настроек BlackVue.





Вы можете изменять такие параметры, как имя и пароль сети Wi-Fi, качество изображения, настройки чувствительности, запись звука вкл / выкл, единицы скорости (км/ч, миль/ч, выкл.), включение/выключение индикаторов, громкость голосового управления, настройка Cloud и др.

Дополнительная информация об изменении настроек в BlackVue Viewer есть в руководстве, которое можно скачать с сайта <u>www.blackvue.com</u> > Support > Downloads.

ШАГ 4 Подключение к BLACKVUE CLOUD (опционально)

Вы можете пропустить этот шаг, если у вас нет точки доступа к Wi-Fi на мобильном устройстве или соединительного модуля BlackVue, а также если вы не хотите использовать сервис BLACKVUE CLOUD.

Если у вас есть точка доступа к Wi-Fi на мобильном устройстве (переносной маршрутизатор Wi-Fi), соединительный модуль BlackVue (CM100LTE), встроенная беспроводная сеть в автомобиле или сеть Wi-Fi в зоне нахождения автомобиля, вы можете использовать приложение BlackVue, чтобы подключиться к сервису BLACKVUE CLOUD для просмотра местонахождения вашего автомобиля в режиме реального времени или передачи видео с видеорегистратора в режиме реального времени.

Дополнительная информация об использовании приложения BlackVue есть в руководстве BlackVue Cloud, которое можно загрузить на сайте <u>www.blackvue.com</u> > Support > Downloads.

(A) Создание учетной записи

- (i) Откройте приложение BlackVue.
- (ii) Коснитесь кнопки ≡ в верхнем левом углу экрана и выберите Регистрация.
- (iii) Укажите свое имя, адрес своей электронной почты и придумайте пароль.
 Повторно введите пароль и нажмите кнопку Регистрация.
- (iv) Вам будет отправлено электронное сообщение. Перейдите по ссылке в сообщении, чтобы завершить создание учетной записи.

В) Регистрация видеорегистратора в учетной записи

- (i) В приложении BlackVue выберите CLOUD и зайдите в свою учетную запись.
- (ii) Коснитесь «Да», чтобы включить push-уведомления (этот параметр вы можете изменить в любое время).
- (iii) Выберите «Зарегистрировать новую камеру».
- (iv) Зарегистрируйте свою камеру одним из следующих способов:

46 BLACKVUE

Autogoods "130"

QR-код: нажмите «**Сканировать QR-код**» и направьте экран своего смартфона на наклейку с QR-кодом на корпусе камеры;



Русский

или

Регистрация вручную: введите серийный номер своей камеры и код Cloud и нажмите «Зарегистрировать».

С Подключите видеорегистратор BlackVue к точке доступа Wi-Fi, чтобы связаться с сервисом Cloud

- Убедитесь, что ваш видеорегистратор BlackVue и точка доступа к Wi-Fi на мобильном устройстве включены.
- (ii) Выполните сопряжение смартфона с видеорегистратором BlackVue через Wi-Fi Direct (подробнее см. ШАГ 2 «Воспроизведение файлов видеозаписи на смартфоне»)
- (iii) Откройте приложение BlackVue. Выберите WI-FI > 🏟 > Настройки прошивки > CLOUD.



- (iv) Убедитесь, что опция Включить Cloud активна. Выберите Настройки точки подключения к Cloud.
- (v) Выберите из списка свою точку доступа Wi-Fi. Введите пароль и коснитесь **ОК**.



🗐 Примечание

- Можно сохранить до трех SSID точек доступа Wi-Fi (например, домашней сети, переносного устройства и рабочей сети).
- Видеорегистратор BlackVue DR750X не поддерживает беспроводные сети 5 ГГц.



(vi) Вернитесь в меню настроек прошивки, коснитесь 🗸 и выберите Сохранить.

После перезагрузки видеорегистратор автоматически подключится к Интернету. Если подключение к Интернету не установлено, убедитесь, что информация Wi-Fi была введена корректно.

Чтобы воспользоваться функциями сервиса Cloud, выберите CLOUD на главном экране.

🛒 Примечание

 Если для подключения к Интернету доступны точки доступа LTE и Wi-Fi, точка доступа Wi-Fi будет использоваться в приоритетном порядке. Если вы предпочитаете соединение LTE, вы можете в любое время удалить информацию о точке доступа Wi-Fi.

Подключение видеорегистратора BlackVue к облаку (с использованием CM100LTE)

Убедитесь, что ваш видеорегистратор BlackVue имеет возможность подключения соединительного модуля. Затем выполните указанные ниже действия для регистрации SIM-карты.

- (i) Найдите гнездо для SIM-карты. Открутите болт крышки гнезда SIM-карты. Затем извлеките гнездо SIM-карты с помощью специального инструмента. Вставьте карту в гнездо SIM-карты. Установите на место гнездо SIM-карты в соединительный модуль, а затем завинтите болт, который фиксирует крышку гнезда SIM-карты.
- (ii) Выполните сопряжение смартфона с видеорегистратором BlackVue с помощью Wi-Fi Direct. Для этого.
- (iii) Откройте приложение BlackVue и выберите WI-FI > 猾.



- (iv) Настройте параметры APN, чтобы активировать SIM-карту. Для получения более подробной информации см. «Руководство по активации SIM-карты», которое находится в упаковочной коробке, или посетите справочный центр BlackVue: <u>www.helpcenter.blackvue.com</u> -> Руководство по подключению LTE.
- (v) После подключения видеорегистратора к Интернету вы можете перейти в меню CLOUD и использовать функции облака BlackVue Cloud.

🖊 Примечание

- Для получения более подробной информации см. «Руководство по активации SIM-карты», которое входит в состав пакета CM100LTE.
- Чтобы использовать службу BlackVue Cloud, SIM-карта должна быть активирована для доступа в Интернет через сеть LTE.
- Когда видеорегистратор подключен к Интернету, вы можете использовать функции BlackVue Cloud, такие как удаленный просмотр в реальном времени Live View, воспроизведение видео, геолокация в реальном времени, push-уведомления, автозагрузка, удаленное обновление прошивки и т.д., используя приложения BlackVue или Viewer для ПК.
- Некоторые функции облачной службы могут не работать, когда температура окружающей среды слишком высока или/и скорость LTE слишком медленная.
- Дополнительная информация об использовании приложения BlackVue приведена в руководстве BlackVue Cloud, которое можно загрузить на сайте <u>www.blackvue.com</u> > Support > Downloads.

50 BLACKVUE

🕨 Советы по оптимизации производительности

Для стабильной работы видеорегистратора рекомендуется форматировать карту microSD раз в месяц.

Форматирование с помощью BlackVue Viewer (Windows):

Загрузите программу BlackVue Windows Viewer на сайте <u>www.blackvue.com</u> > Support > Downloads и установите ее на компьютер. Вставьте карту в устройство для считывания карт microSD и подключите устройство к ПК. Запустите копию BlackVue Viewer, установленную на вашем ПК. Нажмите кнопку «Форматировать» . выберите устройство для считывания карт и нажмите OK.

Форматирование с помощью BlackVue Viewer (macOS):

Загрузите программу BlackVue Mac Viewer на сайте <u>www.blackvue.com</u> > Support > Downloads и установите ее на компьютер. Вставьте карту в устройство для считывания карт microSD и подключите устройство к ПК. Запустите копию BlackVue Viewer, установленную на вашем ПК. Нажмите кнопку «Форматировать» и выберите карту microSD в списке дисков на левой вкладке. После выбора карты microSD нажмите вкладку «Очистить» в основном окне. Выберите «MS-DOS (FAT)» из выпадающего меню «Форматирование хранилища» и нажмите «Очистить».

- Используйте только фирменные карты microSD от BlackVue. При использовании других карт могут возникнуть проблемы с совместимостью.
- Регулярно обновляйте программную прошивку, чтобы улучшить производительность и обновить функции устройства. Обновления прошивки будут доступны для скачивания на сайте <u>www.blackvue.com</u> > Support > Downloads.

Техническая поддержка

Техническую поддержку, руководства и обновления программной прошивки можно получить на сайте <u>www.blackvue.com</u> Также вы можете написать сообщение специалисту технической поддержки по адресу cs@pittasoft.com

> Технические характеристики устройства:

Модель	DR750X-1CH		
Цвет/размер/вес	Черный/ширина 118,5 мм х высота 36 мм/103 г		
Память	Карта памяти microSD (32 ГБ/64 ГБ/128 ГБ/256 ГБ)		
Режимы записи	Обычная запись, запись событий (при обнаружении воздействия в нормальном режиме и режиме парковки), запись вручную и в режиме парковки (при обнаружении движения) * При использовании силового кабеля клемма ACC+ включает режим парковки. При использовании других методов режим парковки включается с помощью гироскопа.		
Камера	Датчик STARVIS™ CMOS (прибл. 2,1 Мп)		
Угол обзора	По диагонали 139°, по горизонтали 116°, по вертикали 61°		
Разрешение/ частота кадров	Full HD с частотой 60 кадров в секунду * Частота кадров может меняться во время потоковой передачи по Wi-Fi.		
Качество изображения	Наивысшее (Экстрим), Наивысшее, высокое, нормальное		
Режим сжатия видео	MP4		
Wi-Fi	Встроенный (802.11 b.g.n)		
GPS	Встроенный (двухдиапазонный: GPS, GLONASS)		
Bluetooth	Встроенный (V2.1+EDR/4.2)		
LTE	Внешний		
Микрофон	Встроенный		

Динамик (Голосовое управление)	Встроенный			
Светодиодные индикаторы	Индикаторы записи, GPS/BT, LTE/Wi-Fi, системы безопасности передней камеры, датчика близости			
Кнопки	Кнопка WI-FI: * Нажмите один раз, чтобы включить/выключить Wi-Fi. Датчик близости: При касании датчика присутствия включается/ отключается аудиозапись или запускается запись вручную в зависимости от настроек программной прошивки.			
Датчик	3-осевой датчик ускорения			
Резервная батарея	Встроенный конденсатор			
Входное напряжение	12–24 В пост. тока (разъем пост. тока [Ø3,5 x Ø1,35]) для кабелей (черный: GND/желтый: B+ / красный: ACC)			
Потребление тока	Обычный режим (Wi-Fi вкл. / GPS вкл.): 275 мА/час Обычный режим (Wi-Fi выкл. / GPS вкл.): 240 мА/час Режим парковки (Wi-Fi вкл. / GPS выкл.): 220 мА/час Режим парковки (Wi-Fi выкл. / GPS выкл.): 185 мА/час * Фактическое потребление энергии может различаться в зависимости от условий использования и окружающей среды.			
Рабочая температура	-20 °C – 85 °C (-4 °F – 185 °F)			
Температура хранения	-20 °C – 90 °C (-4 °F – 194 °F)			
Выключение питания при перегреве	Прибл. 85°С (185°F)			

Сертификаты соответствия	FCC, CE, RoHS, Telec, WEEE, IC
Программное обеспечение	Программа BlackVue Viewer * Поддерживаются Windows 7 или более поздние версии и Mac Yosemite OS X (10.10) или более поздние версии
Приложение	Приложение BlackVue (Android 5.0 или выше, iOS 9.0 или выше)
Другое	Адаптивная система управления файлами, не требующая форматирования

* STARVIS является торговой маркой Корпорации Sony.

54 BLACKVUE







Product Warranty

- The term of this product warranty is 1 year from the purchase date. (Accessories such as an External Battery/microSD Card: 6 Months)
- We, PittaSoft Co., Ltd., provide the product warranty according to the Consumer Dispute Settlement Regulations (drawn up by the Fair Trade Commission). PittaSoft or designated partners will provide the warranty service upon request.

Circumstances			Warranty	
			Within the Term	Outside of the Term
	For serious repair purchase	required within 10 days of	Exchange/ Refund	
	For serious repair purchase	required within 1 month of	Exchange	N/A
	For serious repair exchange	required within 1 month of	Exchange/ Refund	
	When not exchan	geable	Refund	
For performance/		For Defect	Free Repair	
for pirotinance functional problems under normal use conditions	Repair (If Available)	Repeated problem with the same defect (up to 3 times)	Exchange/ Refund	Paid Repair/ Paid Product Exchange
		Repeated trouble with different parts (up to 5 times)		
	Repair (If Unavailable)	For the loss of a product while being serviced/repaired		Refund after depreciation
		When repair is unavailable due to lack of spare parts within the component holding period		plus an additional 10% (Maximum: purchase price)
		When repair is unavailable even when spare parts are available		Exchange/ Refund after depreciation
 Malfunction due Malfunction due Malfunction damage, unre Malfunction an unauthori Service Cente Malfunction & consumables, Other Cases Malfunction c Expired life sg. Malfunction c 	eto customer fault & damage caused easonable operation, n & damage afte zed third party, and r. & damage due to the or separately sold p lue to natural disast pan of a consumable lue to external reaso	I by user negligence (fall, shock, etc.) or careless use er being serviced/repaired by not through Pittasoft's Authorized use of unauthorized components, arts ers (fire, flood, earthquake, etc.) part ms	Paid Repair	Paid Repair

This warranty is only valid in the country where you purchased the product.

Гарантия

Срок гарантии на данное устройство составляет 1 год с даты покупки. (для аксессуаров, таких как батарея/карта памяти microSD: 6 месяцев)

Мы, компания PittaSoft Co., Ltd, предоставляем гарантию на продукт в соответствии с правилами урегулирования потребительских споров (составленными Комиссией по справедливой торговле). PittaSoft или авторизованные партнеры облукотся обсегичавть сервисные услуги по запросу.

Название продукт (название модели	та и)		Серийный номер		
Дата покупки		Место покупки		ки	
Информация о клиенте		Адрес/телефо		он	
				, i	Гарантия
Поврежден	ия, полученные	во время эксплуа	тации	во время гарантийно срока	по истечении гарантийного срока
	Если требуется 14 дней со дня	и требуется крупный ремонт в первые ней со дня покупки		Замена/ возврат стоимости	и Отсутствует
	При невозмож	и невозможности замены			ие
Если неисправность возникла не по вине клиента (производственный дефект)		Для дефектов		Бесплатны ремонт	ій
	ремонт при наличии возможности	Повторное обращение в связи с одинаковой неисправностью (до 3 раз)			
		Повторное обращение с различной неисправностью (до 5 раз)			Платный ремонт/
		Невозможност сервисного обс	ь выполнения луживания	Замена/ возмещени	платная замен ие устройства
	если ремонт	При невозможности ремонта из-за отсутствия запасных частей в течение срока ремонта			
	невозможен				
		При невозможн даже при налич частей	юсти ремонта нии запасных		
1) Неисправности, возн	никшие по вине по	растей Ользователя			
(падение, удары, п	ювреждения, непр	авильное использо	ование и т.д.)		
 Неисправности и 	повреждения, воз	вникшие после рем	юнта,		
 Неисправности и 	че в авторизованн повреждения, пол	юм сервисном цен 174енные в резуль	тате		
несанкционированного использования компонентов, расходных				Платный Платный	Платный
материалов или ч	астей, продающих	хся отдельно.		ремонт	ремонт
2) Другие случаи			e		
- пенсиравности, полученные в результате стилииных оедствий (пожар, наволнение, землетрясение и т.п.)					
 Истечение срока с 	службы расходных	х материалов			
 Неисправности, п 	 Неисправности, полученные вследствие внешних причин 				

Эта гарантия действительна только в той стране, где был приобретен продукт.



FCC ID : YCK-DR750X-2CH / HVIN : DR750X-1CH / IC : 23402-DR750X2CH

Product	T	Car Dashcam
Model Name	T	DR750X-1CH
Manufacturer	T.	Pittasoft Co., Ltd.
Address	L	4F ABN Tower, 331, Pangyo-ro, Bundang-gu, Seongnam-si,
		Gyeonggi-do, Republic of Korea, 13488
Customer Support	1	cs@pittasoft.com
Product Warranty	T	One-Year Limited Warranty
facebook.com/E	Blac	kVueOfficial
instagram.com/	bla	ackvueofficial
www.blackvue.co	m	
Made in Korea		

COPYRIGHT©2020 Pittasoft Co., Ltd. All rights reserved.

Autogoods "130"